




FEATHERWEIGHT™ Vacuum

USER GUIDE
2033 SERIES



IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING YOUR VACUUM.

Always connect to a polarized outlet (one slot is wider than the other). Unplug from outlet when not in use and before conducting maintenance. When using an electrical appliance, basic precautions should be observed, including the following:

WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- » Always connect to a polarized outlet (one slot is wider than the other). Do not modify the polarized plug to fit a non-polarized outlet or extension cord.
- » Do not leave vacuum cleaner when it is plugged in. Unplug from outlet when not in use and before servicing.
- » Do not use outdoors or on wet surfaces.
- » Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- » Do not use for any purpose other than described in this user guide. Use only manufacturer's recommended attachments.
- » Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, have it repaired at an authorized service center.
- » Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- » Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- » Do not handle plug or vacuum cleaner with wet hands.
- » Do not put any object into openings. Do not use with any opening blocked; keep openings free of dust, lint, hair, and anything that may reduce air flow.
- » Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- » Turn OFF all controls before plugging or unplugging vacuum cleaner.
- » Use extra care when cleaning on stairs.
- » Do not use to pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- » Do not use vacuum cleaner in an enclosed space filled with vapors given off by oil-based paint, paint thinner, some moth-proofing substances, flammable dust, or other explosive or toxic vapors.
- » Do not use to pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- » Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- » Do not use without filters in place.
- » Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
- » Use only on dry, indoor surfaces.
- » Keep appliance on a level surface.
- » Do not carry the vacuum cleaner while it is running.

SAVE THESE INSTRUCTIONS FOR FUTURE USE

This model is for household use only.

THIS APPLIANCE HAS A POLARIZED PLUG

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a proper outlet. Do not change the plug in any way.

Thanks for buying a BISSELL® vacuum!


We love to clean and we're excited to share one of our innovative products with you. We want to make sure your vacuum works as well as it does today for years to come, so this guide has tips on using, maintaining, and if there is a problem, troubleshooting.

Your vacuum needs a little assembly before you can put it to work, so flip to page 4 and let's get started!

| | | | |
|--------------------------|---|---------------------------|---|
| Safety Instructions..... | 2 | Troubleshooting..... | 6 |
| Product View..... | 3 | Warranty..... | 7 |
| Operations..... | 4 | Service..... | 7 |
| Maintenance & Care..... | 5 | Product Registration..... | 8 |

Product View

- 1 Hand Grip
- 2 Cord Wrap
- 3 Power Cord
- 4 Handle
- 5 Quick Release Handle
- 6 Hand Vacuum Grip
- 7 Power Switch
- 8 Dirt Tank Latch
- 9 Filter (inside Dirt Tank)
- 10 Dirt Tank
- 11 Removable Floor Nozzle
- 12 Date Code and Serial Number



How to Use Your Vacuum

WARNING

Do not operate vacuum with damp or wet filters or without all filters in place.

Your Featherweight™ vacuum may be used in three ways:


- Floor vacuum
- Hand Vacuum
- Multi-Purpose Vacuum

1




To use as a floor vacuum, open the latch at the top of the Hand Vacuum Grip and insert Handle. Once Handle is all the way inserted into the body of the vacuum, press the latch closed to secure the Handle in place.

2



Then, attach the floor nozzle by inserting it into the opening at the bottom of the Dirt Tank. Press firmly to secure in place.

3



To use as a hand vacuum, release the latch from the Handle and pull Handle away from the machine. Press the latch closed.

4



The floor nozzle may be used with the hand vacuum for multi-purpose cleaning. To attach the floor nozzle, insert it into the opening at the bottom of the Dirt Tank. Press firmly to secure in place.

Power Cord Storage





Turn vacuum OFF and unplug Power Cord by grasping the polarized plug, NOT the cord, and disconnecting it from othe outlet. Loop Power Cord around Cord Wraps on the Handle and clip the molded plug to Power Cord to secure.

Emptying the Dirt Tank


⚠️ WARNING

To reduce the risk of electrical shock, turn Power Switch OFF and disconnect polarized plug from electrical outlet before performing maintenance or troubleshooting checks.



NOTE: The Dirt Tank may be rinsed with warm water and a mild detergent if needed. The Dirt Tank must be thoroughly dried before replacing.

Cleaning the Filter



NOTE: After heavy usage, you may clean the Filter by washing it gently by hand in warm water and mild dish detergent. Rinse thoroughly and make certain it is completely dry before replacing it. If filter is torn, replace it with a new filter.

Troubleshooting

WARNING

To reduce the risk of electrical shock, turn Power Switch OFF and disconnect polarized plug from electrical outlet before performing maintenance or troubleshooting checks.

| Problem | Possible causes | Remedies |
|--|--|---|
| Vacuum cleaner won't run | Power Cord not firmly plugged in. | Check electrical outlet. |
| | Blown household fuse or breaker. | Check/replace fuse; reset breaker. |
| Vacuum cleaner won't vacuum effectively | Filter clogged, wet or dirty. | Follow instructions for "Cleaning the Filter". |
| | Dirt Tank clogged. | Follow instructions for "Emptying the Dirt Tank". |
| Dust blows out of air vent | Filter not properly secured to filter frame. | Follow instructions for replacing Filter above. |

Warranty

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. If you need additional instruction regarding this warranty or have questions regarding what it may cover, please contact BISSELL Consumer Care by E-mail or telephone as described below.

It may be necessary to obtain some of your personal information, such as a mailing address, to fulfill terms of this warranty. Any personal data will be handled pursuant to BISSELL's Privacy Policy, which can be found online at www.BISSELL.com/privacy-policy.

Limited One-Year Warranty

Subject to the ***Exceptions and Exclusions from the Terms of the Limited Warranty**, upon receipt of the product BISSELL will repair or replace (with new, refurbished, lightly used, or remanufactured components or products), at BISSELL's option, free of charge from the date of purchase by the original purchaser, for one year, any defective or malfunctioning part.

See information below on "If your BISSELL product should require service".

This warranty applies to product used for personal, and not commercial or rental, service. This warranty does not apply to fans or routine maintenance components such as filters, belts or brushes. Damage or

malfunction caused by negligence, abuse, neglect, unauthorized repair, or any other use not in accordance with the user guide is not covered. This warranty will only be valid if the product is used in the same country in which it was sold.

BISSELL is not liable for incidental or consequential damages of any nature associated with the use of this product. BISSELL's liability will not exceed the purchase price of the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

*Exceptions and Exclusions from the Terms of the Limited Warranty

This warranty is exclusive and in lieu of any other warranties, either oral or written. Any implied warranties, which may arise by operation of law, including the implied warranties of merchantability and fitness for a particular purpose, are limited to the one-year duration from the date of purchase as described above.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

NOTE: Please keep your original sales receipt. It provides proof of date of purchase in the event of a warranty claim.

Service

Please do not return this product to the store.

Other maintenance or service not included in the manual should be performed by an authorized service representative.

If your BISSELL® product should require service:

Contact BISSELL Consumer Care to locate a BISSELL Authorized Service Center in your area. If you need information about repairs or replacement parts, or if you have questions about your warranty, contact BISSELL Consumer Care.

Website:

www.BISSELL.com/service-centers

E-mail:

www.BISSELL.com/email-us

Call:

BISSELL Consumer Care
1-800-237-7691

Register your product today!

Registering is quick, easy and offers you benefits over the lifetime of your product. You'll receive:

BISSELL® Rewards Points

Automatically earn points for discounts and free shipping on future purchases.

Faster Service

Supplying your information now saves you time should you need to contact us with questions regarding your product.

Product Support Reminders and Alerts

We'll contact you with any important product maintenance reminders and alerts.

Special Promotions

Optional: Register your email to receive notice of offers, contests, cleaning tips, and more!

Visit BISSELL.com/registration!

Parts & Supplies

For Parts and Supplies, go to www.BISSELL.com and enter your model number in the search field.

We're Waggin' Our Tails!

BISSELL proudly supports BISSELL Pet Foundation® and its mission to help save homeless pets. When you buy a BISSELL product, you help save pets, too. We're proud to design products that help make pet messes, odors and pet homelessness disappear.

Visit **BISSELLsavespets.com** to learn more.



Love your **BISSELL®** product?

Don't keep it a secret.
Let us, and millions of others, know what you think!
Leave your star-rating on BISSELL.com

www.BISSELL.com



©2020 BISSELL Inc. All rights reserved.
Printed in China. Part Number 1623526 01/20 RevA