

Model 5308V

Owner's Guide

This product is intended for installation by a professional installer only! Attempts to install this product by a person other than a trained professional may result in severe damage to a vehicle's electrical system and components.

Congratulations

Congratulations on the purchase of your VIPER® system. Reading this Owner's Guide prior to using your system will help maximize the use of your system and its many features. For additional information please contact your Authorized Dealer or visit www.viper.com.

After installation is completed, you should receive:

- One 2-Way LCD remote control (P/N: 7347V)
- One 1-Way remote control (P/N: 7147VS)
- Owner's Quick Reference Card



Important Information

Safety Information



Warning! Failure to heed the information in this guide can result in death, personal injury or property damage, and may also result in the illegal use of the system beyond its intended purpose.

Your Warranty

Your system comes with a warranty. The warranty terms are detailed at the end of this guide. Make sure that you receive proof of purchase from your dealer, indicating the product was installed by an Authorized Dealer.

Replacement Remote Controls

Please see your Authorized Dealer or visit us at www.viper.com to order additional remote controls. Remote control part numbers are found on the back of the remote.

System Maintenance

This system needs no specific maintenance beyond remote control battery replacement. See 'Battery Information' section for more details.

2-Way Remote Control




Feature	Description
Internal Antenna	Used for transmitting and receiving information.
Display	LCD screen provides visual confirmation of system status.
Programming (P) button	Used for remote control customization and vehicle selection.
Command buttons	Used to perform locking, unlocking, arming and disarming, remote starting, auxiliary channel and panic activation.
Battery Compartment	(1) CR2450 battery powers the remote control. Remove door on rear of remote case to access.

1-Way Remote Control



Feature	Description
Internal Antenna	Used for transmitting information
Transmit LED	Active when transmitting information
Command buttons	Used to perform locking, unlocking, arming and disarming, remote starting, auxiliary channel and panic activation.

Control Center




The Control Center, typically located on the upper part of the front windshield. It consists of:














- The In-vehicle system antenna, used for system and remote control communication.
- The Status LED, as a visual indicator of the system's status.
- The Control (or Valet) button, for placing the system into Valet Mode and performing various user functions.





* See Valet Mode and Disarming without a Transmitter in the 'Using your System' section of this guide.

LCD Screen






LCD Icon descriptions	
1. Transmit	10. Battery level indicator
2. Out-of-range	11. Remote Start
3. Receive	12. Remote sending
4. Aux Output & Alarm Zone	13. Vibrate mode
5. Warn Away	14. Ignition
6. Audible Mode	15. Vehicle number
7. Alarm	15. Door
8. Trunk or Hood	16. Arm
9. Sensor	17. Disarm





Icon	Description
	On during remote command transmission to the vehicle.
	On during remote command transmission to vehicle, but command page is not received.
	On during receipt of page from the vehicle to the remote.
	Displays which auxiliary is operating, or which security sensor is in Warn Away or alarm state.
	Displays when the engine is running
	Displays when a security feature is tripped, but not to full alarm.
	Displays when a security is tripped to a full alarm state.
	Trunk / Hood icon flashes a few seconds during full alarm and then remains displayed until page is cleared.
	Shock sensor icon flashes a few seconds during Warn Away and full alarm, and then remains displayed until page is cleared.
	Battery icon displays current charge capacity of the remote's battery.
	Bar indicates remote is sending.
	Vibrator icon displays if remote is programmed for vibrator notification. (See remote Programming section)
	Ignition icon flashes a few seconds during full alarm, then remains displayed until page is cleared.

Icon	Description
	Displays the vehicle (1of 4) that the remote controls. See “Vehicle Select” section.
	Door icon flashes a few seconds, and then remains displayed until page is cleared.
	Arm icon flashes when doors are locking, and then remains displayed until the system is disarmed.
	Disarm icon flashes when doors are unlocking, and then remains displayed until the system is armed.

Remote Control Command Table

Basic Remote Functions

Button	Function
	ARM
	DISARM
AUX	TRUNK / AUX
	REMOTE START
P	PROGRAMMING *

Button	Function
 + AUX	AUX 2
 + AUX	AUX 3
 + 	AUX 4

*2-way LCD remote only

Remote Control Functions

The remote control buttons are used to send commands to the system. The descriptions below reflect the standard configuration for this system.

Arm/Lock

Press and release **LOCK**.

The doors lock and the system is armed.

Disarm/Unlock

Press and release **UNLOCK**.

The doors unlock and the system is disarmed.

Silent Arm/Disarm

'Silent Mode' works by pressing the **AUX** button for less than one second before arming or disarming.

Remote Start

Press and release **STAR**.

Activates (or if ON, deactivates) the remote starter. The engine and parking lights turn ON.

Note: The factory setting is one press, but this can also be programmed for two presses (See your Authorized Dealer for the number of presses programmed).

Presses to activate remote start:_____.

Panic

Press and hold **LOCK**.

The panic feature is controlled by pressing this button for two seconds.

Aux 1

Press and hold **AUX**.

An optional auxiliary function, such as trunk release, can be controlled by pressing this button for 1.5 seconds.)

The Aux 1 output controls _____.

AUX 2

Press **LOCK** and **AUX** simultaneously. An optional auxiliary convenience or expansion function that you have added to your system can be activated by pressing these buttons simultaneously. The Aux 2 output controls _____.

AUX 3

Press **UNLOCK** and **AUX** simultaneously. An optional auxiliary convenience or expansion function that you have added to your system can be activated by pressing these buttons simultaneously. The Aux 3 output controls _____.

AUX 4

Press **UNLOCK** and **STAR** simultaneously. An optional auxiliary convenience or expansion function that you have added to your system can be activated by pressing these buttons simultaneously. The Aux 4 output controls _____.

Timer Mode

Press **LOCK** and **UNLOCK** buttons simultaneously.

There are two types of timer modes and the system can be programmed to perform either one or the other, the factory setting is timed mode. In timed mode, the system allows you to keep the engine warm by automatically activating the remote start every three hours for a maximum of six starting cycles.

The temperature mode checks every three hours to see if the temperature threshold of 0°F has been met or exceeded. If met or exceeded, the vehicle then remote starts and runs for the programmed time and will check again three hours after shutting off. However, if the threshold isn't met or exceeded, then the remote start does not activate, but will check again later after another three hours have elapsed.

Note: The timer mode features are activated and deactivated the same way, with the temperature mode automatically exiting after 18 hours.

To Activate:

1. Park the vehicle and set the parking brake.
2. Press the **LOCK** and **UNLOCK** buttons simultaneously. The parking lights flash slowly four times.

The remote start activates and runs for the set duration. The system remains remote started unless shut down by pressing the **STAR** button on the remote.

Once the remote start shuts down, the vehicle will start every three hours for a maximum of six cycles or until timer mode is canceled by turning on the ignition or activating any of the shut-downs (the parking lights flash slowly four times to confirm Timer Mode is exited).

To Deactivate:

Turn on the ignition or activate any of the remote start shutdowns (arming and disarming the system or pressing the **LOCK** and **UNLOCK** buttons on the remote will not exit the timer mode).

The parking lights flash four times confirming timer mode is exiting.

Note: The feature exits (if active) when the vehicle is driven, so if timer mode is desired, it needs to be activated again.

Short-run Turbo Mode

Press **STAR** and **AUX** buttons simultaneously.

Short-run turbo mode keeps the engine running for a programmable period of time, after arriving at your destination (check with your Authorized Dealer for available options). This allows the system's timer to conveniently cool down the turbo after you have left the vehicle.

To Activate:

1. Park the vehicle and set the parking brake.
2. Remove your foot from the brake pedal and leave the engine running.
3. Press the **STAR** and **AUX** buttons simultaneously
The parking lights flash to indicate the remote start has entered the short-run turbo mode.
4. Turn the key to the off position and the engine will continue to run.
5. Exit and secure the vehicle.
The engine will shut off after the programmed runtime expires.

Optional Rear Window Defogger

When the feature is programmed on, the rear defogger automatically activates during the remote start sequence if the temperature at the control module is below 55°F. If the temperature is greater than 55°F at the control module when the remote start is activated, the rear defogger does not turn on.

2-Way Remote Paging

Signal paging features

A page is the signal the control module sends to the remote control as confirmation of receipt of a command or alarm system status. When the remote control receives a page, it generates a page notification to the user (notifications are audible beeps and/or vibration), and the LCD icons display current system status.

Command Page

When a command (arm/disarm, or auxiliary channel) from the remote control is sent and received, the system will send a command page back to confirm receipt.

Alarm Page

If the alarm system is triggered while armed, an Alarm Page will be sent to the remote control. When the remote receives an Alarm Page, the LCD icons will display the alarm system status information, and the remote control will generate beeps and/or vibration. An Alarm Page alert is a series of 5 groups of 4 rapid beeps (shock, trunk, door, ignition, or hood trigger) and the LCD icon that caused the alarm will display. The remote will beep and or vibrate every 60 seconds to alert the user that the alarm system was triggered and will continue until the alarm page is cleared.

Page Recognition (Acknowledgement)

To clear a page alert/notification, quickly press any button on the remote control. This can be performed at any time during or after the page notification has occurred. The remote control will not send a command to the system at this time; it will only clear future repeats of the page notification.

The next time a button is pressed on the remote control it will send a command to the system.

Out of range notification

If a command is issued from the remote, but the remote is set to the incorrect vehicle or is beyond the range of the vehicle to receive the command, the remote responds with 3 sets of 2 quick beeps and the transmit icon (#2) will flash 3-times.





Programming your 2-Way Remote

To enter programming mode:

Press and hold the **P** button located on the side of the remote control until one long beep sounds. You can now customize the remote's response feedback. If no buttons are pressed within 5 seconds, programming mode is exited; the remote sounds 2 beeps.

Beeps and Vibration, ON/OFF

Press **LOCK** to select beep/vibration ON or OFF, or one of the below settings.

Beeps/Vibrate	Response	Icon*
Beeps only	1 beep	
Vibrate only	1 vibrate	
Beep & Vibrate	1 beep & 1 vibrate	 & 
No Beep & No Vibrate	1 long beep	

*Displays during programming

Illumination On/Off

Press **UNLOCK** to select LCD backlight illumination ON/OFF. The LCD backlight will illuminate when a remote button is pressed, or an alarm status page is received.

LCD backlight	Response
ON	1 beep
OFF	2 beeps

Page notification

The 2-Way remote control can notify the user of a page by emitting beeps if the vehicle's status changes, for example, if a door is unlocked, or any vehicle violation.

On the 2-way remote, press **STAR** to select page ON/OFF. One beep is page ON. Two beeps is page OFF.

When programmed off the remote does not give any notification that a page was received from the vehicle.

Page Notifications	Response
ON	1 beep
OFF	2 beeps

Note: If programmed OFF, the remote receives no notification of alarm triggers. The remote only receives command, such as arm or disarm, information.

Vehicle Select

If multiple cars are used with the system: Press **P** for 1-second and release (holding for too long enters programming mode) to select which vehicle is to be controlled by the remote control. Repeat this procedure to scroll to next vehicle selection.

Note: If a Warn Away or alarm trigger occurs in a vehicle not selected, remote control functions automatically switch to that specific vehicle and remains in this vehicle select state. The vehicle select procedure must be used to return to the previous vehicle selection.

Using Your System

Active arming

You can arm the system by pressing **LOCK** for one second. When the system arms you will hear a short siren sound or chirp, and the parking lights flash once. If the vehicle's power door locks have been connected to the system, the doors lock.

While the system is armed the status LED flashes once per second, indicating that the system is active and protecting your vehicle. If you hear a second chirp after arming and see the status LED flashing in groups, refer to the 'Diagnostics' section of this guide. This extra chirp is called 'Bypass Notification'.

Passive arming

The system can be programmed to arm itself automatically, this is called passive arming. If the system is programmed for passive arming, it will automatically arm 30 seconds after the ignition is turned off and the system detects that you have left the vehicle by opening and closing a door.

Whenever the system is in its 30-second passive arming countdown, the status LED flashes twice as fast as it does when the system is armed. The siren chirps one time 20-seconds after the last door has been closed to indicate that the system is about to arm. At the 30-second point the parking lights flash to indicate that the system is armed.

If any protected entry point (such as a door or a switch-protected trunk or hood) is open, the system will not passively arm (unless forced passive arming is programmed ON. See 'Programming Options' section of this guide.) Additionally, if a door, hood or trunk is triggered during the arming countdown, the 30-second countdown starts over.

When the system is armed:

Light impacts trigger Warn Away. When triggered, the siren chirps and the parking lights flash for a few seconds.

Heavy impacts trigger a full alarm response. This consists of the siren sounding continuously and the parking lights flashing for a pre-programmed period, which can range in duration from 1 to 180 seconds.

If a door is opened, the system will immediately start chirping the siren and flash the parking lights. Three seconds later, the siren output changes to a continuous blast. This progressive response gives you time to disarm the system with your remote if you inadvertently open the door while the system is armed.

Turning on the ignition will trip the same progressive response as opening a door.

The optional starter interrupt prevents the vehicle from starting.

Multi-level Security Arming

Multi-Level Security Arming allows you to select which of the security system's inputs or sensors are active or are bypassed when the system is armed (See the Table of Zones section). Press **LOCK** one time to arm the system, siren chirps one time.

Pressing **LOCK** again activates Multi-Level Security Arming.

Each time **LOCK** is pressed consecutively, a different security level is selected, as described in the below table:

Press LOCK	Siren chirps	Zone bypassed
Twice	Twice followed by 1 long chirp	2
3 times	3 times followed by 1 long chirp	4
4 times	4 times followed by 1 long chirp	2 & 4
5 times	5 times followed by 1 long chirp	All zones except 5

Each press of the **LOCK** button ascends to the next security level.

Multi-Level Security Arming applies to a single arming cycle. Once the system is disarmed and then re-armed, all the zones will be active again.

Arming While Driving

Your system can be armed while driving the vehicle.

Press **LOCK** on your transmitter for two seconds while the vehicle is running or while the ignition is on. The siren chirps once, and then once more indicating that the ignition is on. The security system does not respond to any input except the door triggers and the starter interrupt (if installed) will not activate. The security system disarms automatically when the ignition is turned off. The siren chirps twice and the LED stops flashing.

Note: If programmed for the optional Vehicle Recovery System (VRS) feature, arming with the transmitter activates the VRS feature. (See VRS section of this guide.)

Disarming

To disarm the system, press **LOCK**. You will hear two chirps, and the parking lights will flash twice. If the power locks are connected to the system, the doors will unlock. If the siren chirps either four or five times when disarming, refer to the Diagnostics section of this guide. This is called Tamper Alert.

High Security Disarm

High Security Disarm makes it possible to silence and reset the system when it is triggering, without disarming. If the system is triggered, and the siren sounds for longer than six seconds, pressing **LOCK** will stop the trigger and return the system to an armed state. The system does not disarm, but rather reset.

This prevents you from disabling the system should you want to disarm without visually checking the vehicle. Pressing **UNLOCK** after resetting the system will disarm the system.

Pressing **UNLOCK** during the first six seconds of the triggered sequence disarms the system immediately. The six second timer is provided for your convenience; in case you accidentally trigger the system.

Disarming Without Your Remote

This feature allows you to disarm the security system without the remote control, should it be lost, damaged, or disabled. To disarm the system without a remote, you must have the vehicle's factory key and know where the Valet button is located. Be sure to check with the installer for the location and the number of presses of the Valet button required to disarm the system.

To disarm the security system:

1. Turn the ignition to the ON position.
2. Press and release the Valet button the preset number of times (1-5 times, 1 is the default setting) within 15 seconds.

After five seconds the system disarms. If the system does not disarm, you may have waited too long. Turn the ignition off and on and try again.

Location of Valet Button _____.

Number of Pulses _____.

The unit responds to one to five pulses of the Valet button when disarming. Check with your installer to discuss how you want the system configured.

Note: As a precaution, if programmed for passive arming the system should be placed into Valet Mode until a remote is available.

Dome Light Control

Security only

The dome light activates for 30 - seconds after the system is disarmed.

Ignition controlled

The dome light activates for 30 - seconds after the ignition is turned OFF. This feature can be programmed ON or OFF, by the dealer.

Silent Mode

To temporarily turn off the arm or disarm chirps, use Silent Mode.

Press **AUX** for less than one second before arming or disarming, and the confirmation chirp(s) will be eliminated for that one operation only. If you want the arm/disarm chirps turned off permanently, your dealer can do this for you.

The Warn Away response to lighter impacts is bypassed if the system is armed using Silent Mode. This ensures that no chirps will be emitted by the siren in an area you want chirp-free. The system is still capable of a full alarm response, but the Warn Away response is bypassed.

Panic Mode

If you are threatened in or near your vehicle, you can attract attention by triggering the system with your remote.

Hold **LOCK** for approximately two seconds, to enter Panic Mode. The siren sounds and the parking lights flash for the programmed siren duration. To stop Panic Mode at any time, press the **LOCK**.

Valet Modes

Remote Valet (Alarm Valet)

Valet mode can be entered and exited by performing the Remote Valet command or manually using the vehicle key and the control button. When entered, the alarm functions are disabled while the convenience features still operate normally.

Arm and Disarm commands lock and unlock the doors.

To enter or exit Valet Mode with the remote:

Open any vehicle door, and then quickly press the following buttons in the sequence indicated.

1. Press **LOCK**.
2. Press **UNLOCK**.
3. Press **LOCK** again.

The status LED lights solidly if you are entering Valet Mode and goes out if you are exiting Valet Mode.

Garage Mode (Remote Start Valet)

Disabling the Remote Start System/Garage Mode

Garage Mode is a safety feature that disables the remote start system if the vehicle is parked in a garage, being serviced, or used by someone unfamiliar with remote start systems.

When Garage Mode is ON, any attempt to start the engine, activate Timer Mode, or enter Pit Stop mode is denied and remote start diagnostics flashes the parking lights nine times.

Turn Garage Mode ON or OFF:

1. Turn the ignition ON then OFF.
2. Within 10 seconds, press and release the Control Center button once.
3. The Control Center LED turns on.

The parking lights flash:

- Nine times quickly when turning on.
- Nine times slowly when turning off

Remote Start

This feature allows you to remotely start and run your vehicle for a programmable period of time. This makes it possible to warm up the engine, as well as adjust the interior temperature of the vehicle with the climate control system. If interior heating or cooling is desired, the climate controls must be preset, and the fan blower must be set to the desired level prior to remote starting the vehicle.



Warning! (1) Never remote start your vehicle when the keys are in the ignition, except when performing Pit Stop mode, and (2) Never start the vehicle if it is not in PARK or NEUTRAL. (3) Do not activate the remote start if the vehicle has a manual transmission.

To remote start the vehicle:

Ensure the parking brake is set, press **STAR** on the remote control once (or the amount of times the system has been programmed to activate the remote start).

The parking lights flash to confirm that the vehicle will attempt to start. With gas vehicles the engine starts four seconds after the parking lights flash. With diesel vehicles the engine starts when the WAIT-TO-START indicator on the dashboard goes out or the programmed delay has ended.

Once the vehicle has started, it runs for the pre-programmed period of time (either 12, 24, or 60 minutes; See Programming Options section) or until a shutdown input is triggered.



Warning! It is unsafe to operate a vehicle's motor in a garage or other closed off area. Breathing the exhaust from the vehicle is hazardous to your health. Never activate the remote start in an enclosed space.

When you are ready to drive the vehicle:

1. Turn the ignition ON.
2. Press the brake pedal.
3. Disengage the parking brake.
4. Place the vehicle in gear and drive to your destination.

Note: If the brake pedal is pressed or the parking brake is disengaged before the key is in the ON position, the engine will shut down.

While the vehicle is running during remote start operation, the system monitors the vehicle and automatically shuts down the engine if the system receives any of the following:

- The brake pedal is pressed
- The hood is opened
- The shutdown toggle switch is put into the Off position
- The parking brake is disengaged
- Runtime (12, 24, or 60 minutes) expires
- The remote start activation procedure from the remote is repeated.

Pit Stop Mode

Pit Stop mode allows the vehicle to remain running after the key has been removed from the vehicle. This feature is useful for occasions when you wish to exit and lock the vehicle for short periods of time, but would like to leave the motor running and the climate controls on.

To perform Pit Stop mode:

1. Before turning off the engine, ensure that the parking brake is set.
2. Press and release **STAR** on the remote the number of times the system has been programmed to activate the remote start (or press and release the optional momentary switch). Then wait five seconds.
3. Turn the ignition key to the OFF position, the engine will continue running.
4. Exit and secure the vehicle.

When returning to the vehicle simply disarm the system and follow the previous "When you are ready to drive the vehicle" information.

Note: If you are away from the vehicle for an extended amount of time, the remote start will shut off after the programmed runtime expires or when a shutdown input is received (see the Remote Start section for a complete list of shutdown inputs).

This feature will not work if the brake pedal is being pressed or the parking brake is disengaged.

Nuisance Prevention Circuitry

Your system has Nuisance Prevention Circuitry (NPC). It prevents annoying repetitive trigger sequences due to faulty door pin switches or environmental conditions such as thunder, jackhammers, or airport noise.

For example, if the alarm triggers three times within a 60-minute period and each time the same sensor or switch triggers the alarm, NPC will interpret those triggers as false alarms. After the third trigger, NPC ignores, or bypasses that sensor or switch (along with any other sensors or switches sharing the same zone) for 60-minutes.

If the bypassed sensor tries to trigger the system while it is being bypassed, the 60-minute bypass period starts over. This ensures that a sensor that continually triggers will remain bypassed. Doors are covered by NPC differently; if the alarm is triggered by an open door for three full cycles, the doors are bypassed until the trigger ceases.

NPC is ON/OFF programmable, except doors are always covered whether on or off. See your dealer and the 'Programming' section of this guide for more information.

Arming and disarming the system does not reset this function. To reset a bypassed zone, the same zone must not trigger for 60 minutes, or when ignition is turned on. When testing your system, it is important to remember that the NPC programming can cause zones to be bypassed and appear to stop working. If five chirps are heard when disarming, NPC has been engaged. If you wish to clear the NPC memory, turn the ignition key on.

Diagnostics

This security system is constantly monitoring all the switches and sensors that are connected to it. It detects any faulty switches and sensors and prevents them from disabling the entire system. The system will also record and report any triggers that occurred during your absence.

Refer to the 'System Status Chirps' and 'Table of Zones' charts for diagnostic information.

Arming Diagnostics

If the system is armed while an input is active, the unit chirps once when arming and then one more time a few seconds later. This is called Bypass Notification.

Bypass Notification does not occur when using Silent Mode or if chirps have been programmed OFF. The security system continually ignores the zone that was active until the input stops.

Three seconds after the input stops, the system monitors that input normally.

For example, if your vehicle has interior light exit delay and you arm it before the interior light goes out, you may hear Bypass Notification chirps. Once the light shuts off, the doors are monitored normally.

Disarming Diagnostics

Extra disarm chirps are known as Tamper Alerts. If four chirps are heard when disarming, the system was triggered in your absence. If five chirps are heard, a zone was triggered repeatedly, and the Nuisance Prevention Circuitry bypassed that zone (see NPC section of this guide).

The in-vehicle status LED indicates which zone was involved. (See 'Table of Zones' section of this guide.) The system retains this information in its memory and continues to chirp four or five times each time it is disarmed, until the next time the ignition is turned on.

System Status Chirps

The siren chirps when arming and disarming the system. The pattern of chirps audibly reports the system's status as described below.

Action	Chirps	Description
Arm	1	Armed
Arm	(3-second delay) 1	Armed with Bypass Notification
Disarm	2	Disarmed
Disarm	4	Disarmed with Tamper Alert
Disarm	5	Disarmed NPC active

Table of Zones

The zone number is the number of LED flashes used by the system to identify that input. The standard input assignments are listed below.

Note: Warn Away responses are not reported in the table of zones.

Zone/LED Flashes	Description
1	Instant trigger: Often used for trunk pin switch
2	Impact Sensor: a light impact activates Warn away and a heavier impact activates full alarm
3	Door switch trigger
4	Optional sensor inputs for Warn away and full alarm notification
5	Ignition trigger

Interpreting Zone Diagnostics

Warn Away responses are not reported by arming or disarming diagnostics. If you receive a Bypass notification when arming or a Tamper Alert notification when disarming, look at the in-vehicle status LED. Active or triggered zones will be indicated by a pattern of blinks by this LED.

For example: If Zone 3 (door) was active or triggered, the in-vehicle LED will blink three times with a two-second pause. Then it will blink three times again and repeat until the ignition is turned on.

If your system has been triggered but the LED has been reset by turning on the ignition, your dealer can still recall the last zones that were triggered. Contact your dealer for details.

Code Hopping

The receiver and transmitters each use algorithms to change their codes each time the transmitter is used. This technology has been developed to increase the security of the system. The system knows what the next codes should be. This helps to keep the transmitter “in sync” with the control unit even if you use the remote control out of range of the vehicle. However, if the transmitter has been pressed many times out of range of the vehicle, or if the battery has been removed, it may get out of sync with the control unit and fail to operate the system.

To re-sync the remote control, simply press **LOCK** several times within range of the vehicle. The alarm will automatically re-sync and respond to the transmitters normally.

Rapid Resume Logic

If system power is lost and then reconnected, the system will recall the stored state from memory.

This means if the unit is in Valet Mode and the battery is disconnected for any reason, such as servicing the car, when the battery is reconnected, the unit will still be in Valet Mode. This applies to all states of the system including Armed, Disarmed, and Valet Mode.

Power Saver Mode

Your system will automatically enter Power Saver Mode while armed or in Valet Mode, after a period of time in which no operation has been performed. This lowers the current draw to the vehicle's battery. Power Saver Mode takes over under the following conditions:

- Power Saver when the system is armed: After the system has been armed for 24 hours, the in-vehicle LED will flash at half its normal rate, decreasing the system's current draw.
- Power Saver in Valet Mode: When the system enters Valet Mode the in-vehicle LED illuminates steadily. If the vehicle is not used (ignition is not turned on) for a period of one hour while the system is in Valet Mode, the LED will shut off. If the system remains in Valet Mode, the LED will come back on the next time the ignition is turned on and then back off.



Warning! Safety First

Please read the safety warnings below before proceeding. Improper use of the product may be dangerous or illegal.

Installation

Due to the complexity of this system, installation of this product must only be performed by an Authorized Dealer. If you have any questions, ask your Authorized Dealer or contact Customer Service at 1-800-753-0600.

Remote Start Notice

When properly installed, this system can start the vehicle via a command signal from the remote control transmitter. Therefore, never operate the system in an enclosed area or partially enclosed area without ventilation (such as a garage). When parking in an enclosed or partially enclosed area or when having the vehicle serviced, the remote start system must be disabled using 'Garage Mode'. It is the user's sole responsibility to properly handle and keep out of reach from children all remote control transmitters to assure that the system does not unintentionally remote start the vehicle. THE USER MUST INSTALL A CARBON MONOXIDE DETECTOR IN OR ABOUT THE LIVING AREA ADJACENT TO THE VEHICLE. ALL DOORS LEADING FROM ADJACENT LIVING AREAS TO THE ENCLOSED OR PARTIALLY ENCLOSED VEHICLE STORAGE AREA MUST AT ALL TIMES REMAIN CLOSED. These precautions are the sole responsibility of the user.

Before remote starting a vehicle, be sure to:

- Leave the vehicle in PARK and be sure no one is standing in front or behind the vehicle.
- Only remote start on a flat surface.
- Have the parking brake fully engaged.

WARNING! It is the responsibility of the owner to ensure the parking/emergency brake properly functions. Failure to do so can result in personal injury or property damage. We recommend the owner have the parking/emergency brake system inspected and adjusted by a qualified automotive shop biannually.

Use of this product in a manner contrary to its intended mode of operation may result in property damage, personal injury, or death. (1) Never remotely start the vehicle with the vehicle in gear, and (2) Never remotely start the vehicle with the keys in the ignition. The user must also have the neutral safety feature of the vehicle periodically checked, wherein the vehicle must not remotely start while the car is in gear. This testing should be performed by an Authorized Dealer in accordance with the Safety Check outlined in the product installation guide. If the vehicle starts in gear, cease remote start operation immediately and consult with an Authorized Dealer.

OPERATION OF THE REMOTE START MODULE IF THE VEHICLE STARTS IN GEAR IS CONTRARY TO ITS INTENDED MODE OF OPERATION. OPERATING THE REMOTE START SYSTEM UNDER THESE CONDITIONS MAY RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY. YOU MUST IMMEDIATELY CEASE THE USE OF THE UNIT AND SEEK THE ASSISTANCE OF AN AUTHORIZED DEALER TO REPAIR OR DISCONNECT THE INSTALLED REMOTE START MODULE. DIRECTED by VOXX LLC WILL NOT BE HELD RESPONSIBLE OR PAY FOR INSTALLATION OR REINSTALLATION COSTS.

Caution: This product is designed for fuel injected vehicles only.

Upgrades

Upgrades must be performed by an Authorized Dealer. Do not perform any unauthorized modifications to this product.

Battery Information

When the remote control battery begins to weaken, the operating range will be reduced.

Battery Replacement:

If communication range is diminished, or the remote control ceases to function, the remote battery should be replaced. It is recommended to have your battery replaced by an Authorized Dealer. To gain access to the battery, the rear case will need to be separated from the transmitter. In some cases, remotes may have a small security screw(s) that needs to be removed prior to separating.

Note: USB-Rechargeable remote control batteries are not intended to be replaced. If your remote fails to charge, contact your Authorized Dealer.

IMPORTANT: Improper remote disassembly may result in injury or damage to the remote and or battery.

Battery Disposal



We care about the environment. If you need to dispose of the battery, please do so in accordance with your local municipal requirements for battery disposal.

Patent Information

This product may be covered by one or more of the patents found on our website. For a full list of patents, please visit:
www.voxxintl.com/company/patents

Government Regulations

FCC & IC Compliance

This device complies with Part 15 of the FCC Rules and with RSS(s) of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation.

Cet appareil contient un ou plusieurs émetteurs/récepteurs sans licence qui sont conformes aux CNR exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes :

1. Cet appareil ne doit pas causer d'interférences.
2. Cet appareil doit accepter toute interférence, y compris celles qui peuvent causer un fonctionnement indésirable de l'appareil.

Warnings / Avertissements:

1. The device must maintain a separation distance of at least 20cm from the person's body, except for the hands and wrists.
2. Any changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate this equipment.

Warranty Information



LIMITED LIFETIME WARRANTY

DIRECTED by VOXX LLC (the Company) warrants to the original purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within the Lifetime from the date of original purchase in the original vehicle, such defect(s) will be repaired or replaced with new or reconditioned product, (at the Company's option) without charge for parts or repair labor. A transmitter for a vehicle security or remote start system is warranted for 12 months from the date of original purchase.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), authorization number, specification of defect(s), transportation prepaid, to an approved warranty station. This warranty is not transferable.

This Warranty does not cover damage to the vehicle's electrical system or costs incurred for the installation, removal or reinstallation of the product. This Warranty does not cover batteries, broken LCD transmitter display screens, nor apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, abuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s).

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

The company does not warrant that this product cannot be compromised or circumvented. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT WITHOUT INSTALLATION LABOR.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

DIRECTED by VOXX LLC, 2351 J. Lawson Blvd., Suite 110, Orlando, Florida 32824