

# SONY

5-065-762-12(1)



Interchangeable Lens Digital Camera

## FX3

E-mount WW773396/WW277226

Startup Guide



ILME-FX3A

### About the manual for this camera

This guide describes the necessary preparations to start using the product, basic operations, etc. For details, refer to the "Help Guide" (web manual).



"Help Guide" (Web manual)

[https://rd1.sony.net/help/ilc/2510/h\\_zz/](https://rd1.sony.net/help/ilc/2510/h_zz/)

ILME-FX3A Help Guide




## Preparations

### Checking the supplied items

The number in parentheses indicates the number of pieces.

- Camera (1)
- Battery charger (1)
- Rechargeable battery pack NP-FZ100 (1)
- XLR handle unit (1)
- Accessory shoe kit (1)
- Body cap (1) (attached to the camera)
- Shoe cap (1) (attached to the camera)
- Handle shoe cap (1) (attached to the handle)
- Startup Guide (this manual) (1)
- Reference Guide (1)

### Preparing the battery pack



**1** Insert the battery pack into the battery charger, and then connect the battery charger to the USB Type-C® terminal of a USB PD (USB Power Delivery) power supply using a commercially available USB Type-C cable (USB-C® - USB-C).

- Place the battery pack on the battery charger in the direction of ▲. Slide the battery pack in the direction of the arrow as far as it will go.
- Use a USB PD power supply with an output of 30 W (15 V / 2 A) or more and a USB Type-C cable (USB-C - USB-C) that supports 3 A or more.
- Charging is also possible when using a USB PD power supply with output of less than 30 W, but charging may take a long time when charging two batteries at once.
- If you use a USB PD power supply or USB cable with specifications other than those described above, charging may not be performed properly.
- If two batteries are inserted into the battery charger, they will be charged simultaneously.


- Depending on the USB PD power supply, the CHARGE lamp may turn on and off repeatedly before charging starts. However, once the CHARGE lamp or charging status indicator lamps stay lit, charging will proceed normally.

### 2 Insert the battery pack into the camera.

- Open the battery cover, and then insert the battery pack while pressing the lock lever.

### Inserting a memory card into the camera

You can use CFexpress™ Type A memory cards and SD memory cards with this camera.




### Open the memory card cover and insert the memory card into Slot 1.

- Both Slot 1 and Slot 2 support CFexpress Type A memory cards and SD memory cards.
- Insert a CFexpress Type A memory card with the label facing the monitor, and an SD memory card with the terminal facing the monitor. Insert the card until it clicks into place.
- You can change which memory card slot to use by selecting MENU → [Shooting] → [Media] → [Rec. Media Settings] → [Recording Media] or [Recording Media]. The Slot 1 is used in the default settings.

#### Hint

- When you use a memory card with the camera for the first time, it is recommended that you format the card on the camera for more stable performance of the memory card.

### Attaching a lens




- 1** Remove the body cap from the camera and the rear lens cap from the rear of the lens.
- 2** Mount the lens by aligning the two white index marks (mounting indexes) on the lens and camera.
- 3** While pushing the lens lightly toward the camera, turn the lens slowly in the direction of the arrow until it clicks into the locked position.

### Attaching the XLR handle unit (supplied)

By attaching the XLR handle unit, up to four audio devices can be connected to the camera simultaneously.

- 1** Remove the shoe cap from the camera and the handle shoe cap from the XLR handle unit.
- 2** Slide the XLR handle unit into the Multi Interface Shoe until it reaches the back of the shoe. Then, be sure to securely tighten the screws on either side using a coin, etc.



### Performing initial setup for the camera

By establishing a Bluetooth connection (pairing) between the camera and a smartphone, you can perform initial camera setup such as date and time settings from the smartphone. Install the dedicated application on your smartphone in advance, and then follow steps 1 to 3 under "Procedures for initial camera setup."


### Installing the dedicated smartphone application



Install the application from the following website. Also, update to the latest version of the dedicated application. The specifications of the dedicated application may change without notice.

<https://www.sony.net/ca/>

### Procedures for initial camera setup



- 1** Set the power switch to "I" (On) to turn on the camera.
- 2** Select the desired language and then press the center of the control wheel.
- 3** Follow the instructions on the camera screen to connect the camera with your smartphone and perform the initial setup.
  - You can also configure or change the initial settings later from the MENU of the camera.

### Connecting (pairing) the camera with your smartphone later




For details on the connection method, refer to the following Help Guide URL:

[https://rd1.sony.net/help/ilc/2510\\_pairing/h\\_zz/](https://rd1.sony.net/help/ilc/2510_pairing/h_zz/)

## Shooting

### Shooting movies




- 1** Press the MODE (Mode) button, use the control wheel to select [Movie], and then press the center.
- 2** Press the REC (Recording) button to start recording.
 

Movie recording can be started from any shooting mode in the default setting.
- 3** Press the REC button again to stop recording.

### Shooting still images

- 1** Press the MODE (Mode) button, use the control wheel to select the desired shooting mode, and then press the center of the control wheel.
- 2** Press the shutter button halfway down to focus.
- 3** Press the shutter button all the way down.



# Notes on use

**Refer to “Precautions” in the “Help Guide” as well.**

**Notes on handling the product**

- This camera is designed to be dust-and moisture-resistant, but is not waterproof or dust-proof.
- Do not leave the lens exposed to a strong light source such as sunlight. Because of the lens’s condensing function, doing so may cause smoke, fire, or a malfunction inside the camera body or the lens. If you have to leave the camera exposed to a light source such as sunlight, attach the lens cap to the lens.
- If sunlight or other strong light enters the camera through the lens, it may focus inside the camera and cause smoke or fire. Attach the lens cap when storing the camera. When shooting with backlighting, keep the sun sufficiently far away from the angle of view. Even if it is slightly away from the angle of view, smoke or fire may still occur.
- Do not directly expose the lens to beams such as laser beams. That may damage the image sensor and cause the camera to malfunction.
- Do not look at sunlight or a strong light source through the lens when it is detached. This may result in unrecoverable damage to the eyes or cause a malfunction.
- This camera (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this camera close to persons who use such medical devices. Consult your doctor before using this camera if you use any such medical device.
- Increase the volume gradually. Sudden loud noises can damage your ears. Be especially careful when listening to headphones.
- Do not leave this unit, the supplied accessories, or memory cards within the reach of infants. They may be accidentally swallowed. If this occurs, consult a doctor immediately.
- While the cooling fan is in operation, be careful not to let any objects get sucked into the fan.

**Notes on the monitor**

- The monitor is manufactured using extremely high-precision technology, and over 99.99% of the pixels are operational for effective use. However, there may be some small black dots and/ or bright dots (white, red, blue or green in color) that constantly appear on the monitor. These are imperfections due to the manufacturing process and do not affect the recorded images in any way.
- If the monitor is damaged, stop using the camera immediately. The damaged parts may harm your hands, face, etc.

**Notes on continuous shooting**

During continuous shooting, the monitor may flash between the shooting screen and a black screen. If you keep watching the screen in this situation, you may experience uncomfortable symptoms such as feeling of unwellness. If you experience uncomfortable symptoms, stop using the camera, and consult your doctor as necessary.

**Notes on recording for long periods of time or recording 4K movies**

- The camera body and battery may become warm with use – this is normal.
- If the same part of your skin touches the camera for a long period of time while using the camera, even if the camera does not feel hot to you, it may cause symptoms of a low-temperature burn such as redness or blistering. Pay special attention in the following situations and use a tripod, etc.
  - When using the camera in a high temperature environment
  - When someone with poor circulation or impaired skin sensation uses the camera
  - When using the camera with [Auto Power OFF Temp.] set to [High]
- Do not touch the area around the ventilation outlet for long periods of time. Doing so may cause low-temperature burns.

**Notes on using memory cards**

- When recording is finished, the memory card may become hot. This is not a malfunction.
- If  (overheating warning icon) is displayed on the monitor, do not remove the memory card from the camera right away. Instead, wait for a while after turning off the camera, and then remove the memory card. If you touch the memory card while it is hot, you may drop it and the memory card may be damaged. Be careful when removing the memory card.

**Notes on using a tripod**

Use a tripod with a screw less than 5.5 mm (7/32 inches) long. Otherwise, you cannot firmly secure the camera, and damage to the camera may occur.

**Sony lenses/accessories**

Using this unit with products from other manufacturers may affect its performance, leading to accidents or malfunction.

**Warning on copyrights**

Television programs, films, videotapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provisions of the copyright laws.

**Notes on location information**

If you upload and share still images or movies taken with this camera on the Internet while the location information is linked with the dedicated smartphone application, you may accidentally reveal the location information to a third party. To prevent third parties from obtaining your location information, deactivate the [Location Information Linkage] function of the dedicated application.

**Notes on discarding or transferring this product to others**

Before discarding or transferring this product to others, be sure to perform the following operation to protect private information.

- Select [Setting Reset] → [Initialize].

**Notes on discarding or transferring a memory card to others**

Executing [Format] or [Delete] on the camera or a computer may not completely delete the data on the memory card. Before transferring a memory card to others, we recommend that you delete the data completely using data deletion software. When discarding a memory card, we recommend that you physically destroy it.

**Note on network functions**

When you use network functions, unintended third parties on the network may access the camera, depending on the usage environment. For example, unauthorized access to the camera may occur in network environments to which another network device is connected or can connect without permission. Sony bears no responsibility for any loss or damage caused by connecting to such network environments.

**Note on the 5 GHz band for wireless LAN**

When using the wireless LAN function outdoors, set the band to 2.4 GHz by following the procedure below. (WW773396 only)

- MENU →  (Network) → [Wi-Fi] → [Wi-Fi Frequency Band]

**How to turn off wireless network functions (Wi-Fi, etc.) temporarily**

When you board an airplane, etc., you can turn off all wireless network functions temporarily using [Airplane Mode].

**How to turn on or off Wi-Fi function**

Select MENU →  (Network) → [Wi-Fi] → [Wi-Fi Connect] → [On] or [Off].

**How to turn on or off Bluetooth function**

Select MENU →  (Network) → [Bluetooth] → [Bluetooth Function] → [On] or [Off].

**Notes on the XLR handle unit (supplied)**

- Before connecting/disconnecting an external microphone or device to/from the INPUT1 or INPUT2 jack, be sure to set the INPUT1 (LINE/MIC/MIC+48V) or INPUT2 (LINE/MIC/MIC+48V) switch to a position other than “MIC+48V.” Plugging/unplugging the cable into/from the external microphone or device while the switch is set to “MIC+48V” may cause loud noise or a malfunction of the device.
- While recording is in progress, operating and handling noises from the camera or lens may be recorded. Touching the handle while recording is in progress will cause noise to be included in the recording.
- While recording is in progress, do not change the INPUT1 or INPUT2 switch settings.
- If the microphone of the handle is in proximity to a speaker, acoustic feedback may occur. In this case, move the handle away from the speaker to allow the maximum distance between the microphone and the speaker, or lower the speaker volume.
- If dust or water droplets are present on the surface of the microphone, successful recording may not be possible. Be sure to clean the microphone surface before using the handle.
- Turn off the camera before attaching/removing the handle.
- When the handle is connected to the camera and the HANDLE AUDIO ON/OFF switch is set to ON, the internal microphone of the camera cannot record audio input.
- When attaching the handle to the camera, fasten the two handle-attachment screws securely. Using the handle without fastening the handle-attachment screws may damage the Multi Interface Shoe terminal or cause the handle to fall off.

## For Customers in the U.S.A.

For question regarding your product or for the Sony Service Center nearest you, call 1-800-222-SONY (7669) .

**Supplier’s Declaration of Conformity**

Trade Name : SONY

Model : WW773396



Responsible Party : Sony Electronics Inc.

Address : 16535 Via Esprillo, San Diego, CA 92127 U.S.A.

Telephone Number : 858-942-2230



This product contains a button cell or coin battery.

 <b>WARNING</b>	
<p>• <b>INGESTION HAZARD:</b> This product contains a button cell or coin battery. • <b>DEATH</b> or serious injury can occur if ingested. • <b>A swallowed button cell or coin battery can cause Internal Chemical Burns</b> in as little as <b>2 hours.</b> • <b>KEEP</b> new and used batteries <b>OUT OF REACH</b> of <b>CHILDREN</b> • <b>Seek immediate medical attention</b> if a battery is suspected to be swallowed or inserted inside any part of the body.</p>	

- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 55 °C (131 °F) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

This product contains a non-replaceable button/coin cell battery.

Battery type: ML621 or MS621

Nominal Voltage: 3 V

## For Customers in Europe

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 27 Watts in order to achieve the maximum charging speed.
USB PD fast charging



USB PD fast charging

Deactivating the power management function will increase the energy consumption of the product.

**For Customers in the UK**

STATEMENT OF COMPLIANCE

- Model No.: WW773396
- Name and address of the manufacturer’s authorised representative: Sony Europe B.V., The Heights, Brooklands, Weybridge, Surrey KT13 0XW, United Kingdom
- This statement of compliance is issued under the sole responsibility of the manufacturer: Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan
- Object of the statement: Digital Camera
- The object of the statement described above is in compliance with the applicable security requirements in Schedule 1 of S.I. 2023 No. 1007 (Product Security)
- Where applicable, references to the relevant standards used in relation to which compliance is declared:
- Defined support period for security updates: 2027-12-31
- Additional information: Note(s):

Signed for and on behalf of: Sony Europe B.V.



Kris De Pauw  
Vice President

Weybridge, 2024-09-09

Sony Europe B.V.  
Registered Office: The Heights, Brooklands, Weybridge, Surrey, KT13 0XW, United Kingdom · Incorporated in the Netherlands No. 71682147

The support period for security updates can be found on the page linked below. The date given in this document is as of the time of release.

https://compliance.sony.co.uk


Specifications	
<b>Camera</b>	
<b>[System]</b>	
Camera Type: Interchangeable Lens Digital Camera	
Lens: Sony E-mount lens	
<b>[Image sensor]</b>	
Image format: 35 mm full frame (35.6 mm × 23.8 mm), CMOS image sensor	
Number of effective pixels on camera: <ul style="list-style-type: none"><li>Approx. 10 300 000 pixels (movies) / approx. 12 100 000 pixels (still images)</li></ul>	
Total number of pixels on camera: <ul style="list-style-type: none"><li>Approx. 12 900 000 pixels</li></ul>	
<b>[Monitor]</b>	
7.5 cm (3.0 type) TFT drive, touch panel	
<b>[General]</b>	
Rated input: 7.2 V <span><span><span></span></span></span> , 7.3 W (during movie recording)	
Operating temperature: <ul style="list-style-type: none"><li>0 to 40°C (32 to 104°F)</li></ul>	
Storage temperature: <ul style="list-style-type: none"><li>−20 to 55°C (−4 to 131°F)</li></ul>	
Dimensions (W/H/D) (Approx.): <ul style="list-style-type: none"><li>129.7 × 77.8 × 84.5 mm</li> <li>5 1/8 × 3 1/8 × 3 3/8 in.</li></ul>	
Mass (Approx.): <ul style="list-style-type: none"><li>715 g (1 lb 9.3 oz) (including battery pack, SD Card)</li></ul>	
<b>[Wireless LAN]</b>	
WW773396 (see name plate on the bottom of camera)	
Supported format: IEEE 802.11 a/b/g/n/ac	
Frequency band: 2.4 GHz/5 GHz	
WW277226 (see name plate on the bottom of camera)	
Supported format: IEEE 802.11 b/g/n	
Frequency band: 2.4 GHz	

Design and specifications are subject to change without notice.

## Trademarks

- α*** is a trademark of Sony Group Corporation.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- The terms HDMI™, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.
- The CFexpress is a trademark licensed by the CompactFlash Association.
- Wi-Fi, the Wi-Fi logo and Wi-Fi Protected Setup are registered trademarks or trademarks of the Wi-Fi Alliance.
- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
- QR Code is a trademark of Denso Wave Inc.
- In addition, system and product names used in this manual are, in general, trademarks or registered trademarks of their respective developers or manufacturers. However, the ™ or ® marks may not be used in all cases in this manual.

**IMPORTANT – Read the End User Software License Agreement before using your Sony product.** Using your product indicates your acceptance of the End User Software License Agreement. The software license agreement between you and Sony is available at the following URL: (https://rd1.sony.net/help/di/e123/h\_zz/)


<b>https://www.sony.net/SonyInfo/Support/</b>
Additional information on this product and answers to frequently asked questions can be found at our Customer Support Website.

**https://www.sony.net/**