

ASSEMBLY INSTRUCTIONS

Cucina Elegante Kitchen Cart With Single Drop Leaf

PARTS:

- (1) Wooden Cart Top With Drawer And (1) Drop Leaf
- (2) Stainless Steel Shelves
- (4) Stainless Steel Legs
- (1) Stainless Steel Towel Bar

HARDWARE:

- (26) 1/4" Washers
- (24) 1/4" Nuts
- (8) 1/4" x 1-1/4" Carriage Head Bolt
- (16) 1/4" x 1/2" Phillips Head Bolt
- (2) Drop Leaf Supports
- (14) #10 x 3/4" Phillips Head Wood Screws
- (2) 1/4" x 1-1/2" Machine Bolt
- (4) Casters

TOOLS REQUIRED:

- (1) 7/16 Wrench or Socket/Ratchet
- (1) Phillips Screwdriver

CAUTION:

To avoid injury to yourself or damage to the butcher block top, make sure assistance is available when setting the butcher block upright.

NOTE:

Applying bar soap, paste wax, or vaseline to wood screw threads will make them easier to insert. If casters are hard to insert into the legs, crimp the snap ring on the caster stem with a needle nose plier and try to re-insert the caster into the leg.

ASSEMBLY INSTRUCTIONS

1. Make sure the assembly area is clean and on a flat secure surface. Carefully remove all the contents within the box and separate the hardware by size.
 2. Place the wood top face down on a rug, carton or other protected surface. Be careful not to allow the drawer unit to fall out.
 3. Attached the corresponding drop leaf to the cart using the #10 x 3/4" screws. The holes are predrilled.
 4. Using the remaining #10 x 3/4" screws, attach the drop leaf support by fastening the support to the drop leaf and the cart, making sure the larger end of the support (3 hole) is attached to the drop leaf and the smaller end (2 hole) to the apron. The holes are predrilled.
 5. Attach each of the four legs to the outside of the apron corners using two 1/4" x 1-1/4" carriage head bolts with nuts and washers. Do not fully tighten at this time.
 6. Attach the stainless steel shelves to the legs using two 1/4" x 1/2" phillips head bolts with nuts and washers per leg. Do not fully tighten at this time.
 7. Go back and fully tighten the bolts in step 5 and then step 6.
 8. Secure the casters into the bottom of the legs by pushing the caster until they snap into place.
 9. Attach the towel bar into the predrilled holes of the apron using the 1/4" x 1-1/2" machine bolts and washers.
 10. Secure the drawer, then turn the cart upright with assistance.
- Be sure to follow the proper care and maintenance guidelines for your new John Boos & Co. product.



Boos[®] BlockS

