
99-7860

VEHICLE APPLICATIONS

Honda Civic SI 2002



- DIN head unit provision with pocket
- ISO head unit provision with pocket

KIT FEATURES

TOOLS REQUIRED

- Stacked ISO head unit provision
- Double DIN head unit provision
- Phillips screwdriver
- Offset tool

ATION INSTRUCTIONS

Questions? Call the Help Line: (800)253 TECH

Dash Disassembly Kit Features

<u>AB</u>

9

CONTENTS

- DIN Head Unit Provision with Pocket Assembly
- ISO Head Unit Provision with Pocket Assembly
- Double DIN Head Unit Provision Assembly
- Stacked ISO Head Unit Provision Assembly
- Final Assembly


99-7860 • Honda Civic SI 2002

- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Remove the shift knob and unsnap the shifter lever trim panel.
- 3 Using and offset tool remove (2) lower bolts securing the center panel.
- 4 Unsnap and remove the dash trim bezel and disconnect the wiring.

- 5 Remove (3) phillips screws securing the climate control pod to the back of the dash trim bezel and remove the pod.
- 6 Remove (4) phillips screws from each side securing the factory head unit and pocket to the bracket assembly and remove.


NOTE: Removing the glove box and the driver's side lower trim panel may be necessary when removing the shifter level trim panel when not using an offset tool.

99-7860 • Honda Civic SI 2002




Slide the DIN cage into the radio opening of the **Housing** and secure by bending the metal locking tabs down.

See figure A



2 Slide the DIN unit into the cage until it is secure.

See figure B




Snap the housing assembly into the dash trim bezel.

99-7860 • Honda Civic SI 2002

Align the holes in the ISO Snap-In


Brackets with the holes in the head
unit and mount the brackets to the
head unit with the screws supplied
with the unit.

See figure A




Slide the head unit/bracket assembly into the radio opening until the side clips engage.

See figure B




Snap the **ISO trimplate** over the head unit.

See figure **C**



Snap the housing assembly into the dash trim bezel.






Assembled Kit


DIN HEAD UNIT PROVISION WITH POCKET

99-7860 • Honda Civic SI 2002




Align the holes on the factory bracket assembly with the holes on the aftermarkert Double DIN head unit and mount with the screws supplied with the unit.

See figure A




2 Cut and remove the center rib (SHADED) from the **Double DIN Trimplate**.

See figure **B**



Snap the **Double DIN Trimplate** over the head unit.

See figure **C**




Assembled Kit

99-7860 • Honda Civic SI 2002


Align the holes on the factory bracket assembly with the holes on the aftermarket ISO head units and mount with the screws supplied with the units.


See figure A



Snap the **Double DIN Trimplate** over the head unit.

See figure **B**






Assembled Kit

STACKED

ISO HEAD UNIT PROVISION

99-7860 • Honda Civic SI 2002



1 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adaptor (70-1721) and making connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit).

See figure A

- **2** Re-connect the battery terminal and test the unit for proper operation.
- 3 Reassemble dash in the reverse order of page 1 in the Dash Disassembly.