



TEMPLATE 1

USE FOR BUILT-IN TRIM KIT MODEL : **MA-TK3080CK/AA,**
MA-TK3080CT/AA

INSTRUCTION

1. Cut out along cut line (Remove Area).
2. Fold Front and rear fold line, position fold line against front edge of cabinet cutout.
3. Refer the provided Install Manual, make the hole at the top and bottom of cabinets.
4. Remove Template.

CUT OUT
CENTER LINE

CUT LINE

FOLD LINE

POSITION OF SPECIAL SCREW
7 / 64" Drill or #35 Drill

CUT OUT
FRONT

11 9/32"
(287mm)

11 9/32"
(287mm)

22/64"
(8.8mm)

7/64" drill or #35 drill
(6 point)

21 1/2"
(546mm)

24"
(610mm)

11 9/32"
(287mm)

11 9/32"
(287mm)

6 57/64"
(175mm)

6 57/64"
(175mm)

22/64"
(8.8mm)

5mm

620mm

5mm

5mm
18mm

592mm

18mm
5mm