

## Introduction & Features

**\*\*\* This Tech bulletin DOES NOT apply to vehicles equipped with the heated seat option. \*\*\***

Installation of RPK5-GM4102 or RPA-KNOB1 into a Camaro without the heated seats option, requires the trimming of extra plastic on the back side of the blank center inserts to fit correctly into the knobs.

The center inserts are keyed so they will only fit one way, and in one specific knob each.

See the images below for reference of which extra plastic tabs need to be removed, so that the blank center caps will install correctly into the knobs.

## Modification

1. Flip the blank insert face down on a flat surface.
2. Locate the 3 extra plastic tabs present on the blank center insert
3. Carefully trim off these 3 small plastic tabs, to allow the center inserts to fully seat in the climate control knobs.
4. Once these plastic tabs are removed, the center inserts should easily snap into their respective knobs.



Blank Insert Left



Blank Insert Right