

- To ensure adequate ventilation for your refrigerator or freezer, allow a minimum of 2" (50mm) of airspace above the cabinet, 1" (20mm) on each side, and 1 1/2" (30mm) at the rear. (See diagram 1).
- The appliance is intended to be placed against a wall with a free distance not exceeding 3" (75mm).
- Ensure the front face of the bench is aligned to the front corner edge of the refrigerator door. This will allow the door to fully open. (See diagram 2).
- If placing the refrigerator in a corner allow 5 1/2" (140mm) clearance for the door to be able to open. (See diagram 3).

