


# 5800 Wireless Replacement Battery Chart



Product	Battery Type	Product	Battery Type
5800CO	CR123	5816MN	CR123
5800MICRA	CR1620 coin cell	5816OD	AA Lithium (Qty 2)
5800PIR-RES	CR123	5817XT	CR123
5800PIR	CR123	5817CBXT	CR123
5800PIR-COM	CR123	5818	CR123
5800PIR-OD	AA lithium (Qty 4)	5818MNL	AAA lithium*
5800RPS	CR1620 coin cell	5819	CR123
5800SS1	CR2	5819WHS	CR123
5800WAVE	WALYNX-RCHB-SC	5819BRS	CR123
5801	CR123	5820L	AAA lithium*
5802	CR1/3N (not replaceable)	5821	CR123
5802MN	CR2032 coin cell	5827	9 volt alkaline
5802WXT/5802WXT-2	CR2032 coin cell	5828V	AA alkaline (Qty 3)
5804	CR2025 coin cell	5839	9 volt Lithium
5804BD	CR2430 (Qty 2)	5853	CR123 (Qty 2)
5804BDV	CR2430 (Qty 2)	5869	CR123
5804Watch	CR2025 coin cell	5870API-WH	CR2
5805-6	CR2032 coin cell	5870API-GY	CR2
5806	9 volt alkaline (Qty 2)	5878	CR2032 coin cell
5806W3	CR123	5890	CR123 (Qty 2)
5808	CR123 (Qty 2)	5890PI	CR123 (Qty 2)
5808LST	CR123 (Qty 2)	5894PI	CR123 (Qty 3)
5808W3	CR123	5897-35	CR123 (Qty 4)
5809	CR123	5898	AA lithium (Qty 4)
5811	CR2032 coin cell		
5811BR	CR2032 coin cell		
5814	CR2430 coin cell		
5815	CR123		
5816	CR123		
		LYNX Plus/LYNX Touch	LYNXRCHKIT-HC LYNXRCHKIT-SC LYNXRCHKIT-SHA



- Unless specified, quantities are one per product.
- Refer to the instructions of the product for approved battery brands.

\*Lithium is recommended, however Alkaline will also work but with shorter battery life.

**Honeywell**