



Safety Rules for Arlo Rechargeable Batteries

Some Arlo devices use rechargeable batteries and can go wherever you need them. But ALL batteries can EXPLODE, CATCH FIRE and CAUSE BURNS if disassembled, punctured, cut, crushed, short-circuited, incinerated or exposed to water, fire or high temperatures, so you need to handle them with care.

To use Arlo Rechargeable Batteries safely:

- ALWAYS store spare batteries in a cool, dry, ventilated area.
- ALWAYS make sure that the battery compartment is clean and free of any debris before inserting new batteries.
- ALWAYS make sure the battery contacts are aligned.
- ALWAYS keep all batteries away from children.
- ALWAYS follow local waste and recycling laws when throwing used batteries away.
- ALWAYS use an Arlo Power Adapter or an Arlo Charging Station (sold separately) to charge Arlo Rechargeable Batteries.
- NEVER place Arlo Rechargeable Batteries in a pocket, purse, or other receptacle, especially those containing metal objects.
- NEVER store Arlo Rechargeable Batteries with hazardous or combustible materials.
- NEVER let an Arlo Rechargeable Battery or battery compartment get wet—before, during, or after installation. (Remember your Arlo device itself is weatherproof, but its interior battery compartment and batteries aren't!).
- NEVER disassemble, cut, crush, puncture, short-circuit, dispose of in fire or water, or expose your Arlo Rechargeable Battery to temperatures above 60°C (140°F).

Your Arlo device has been specifically designed for use only with Arlo Rechargeable Batteries. Therefore, only use Arlo Rechargeable Batteries with Arlo devices.


TO THE EXTENT PERMISSIBLE BY APPLICABLE LAW, ARLO TECHNOLOGIES DISCLAIMS ALL LIABILITY WHATSOEVER RELATED TO THE USAGE OF ANY BATTERY OTHER THAN ARLO RECHARGEABLE BATTERIES IN YOUR ARLO DEVICE, INCLUDING WITHOUT LIMITATION, FIRE, DAMAGE TO PROPERTY, BODILY INJURY, AND/OR DEATH. YOU ASSUME ANY AND ALL RISKS ASSOCIATED WITH THE USAGE OF ANY BATTERY OTHER THAN ARLO RECHARGEABLE BATTERIES IN ARLO DEVICES, INCLUDING WITHOUT LIMITATION, FIRE, DAMAGE TO PROPERTY, BODILY INJURY, AND/OR DEATH.

TO THE EXTENT PERMISSIBLE BY APPLICABLE LAW, FAILURE TO FOLLOW THESE WARNINGS AND/OR DIRECTIONS COULD RESULT IN DAMAGE TO YOUR ARLO DEVICE THAT WILL NOT BE COVERED BY ARLO'S WARRANTY.

ALWAYS REMEMBER that poor quality or mishandled batteries can damage your devices, cause a fire, or result in personal injury. Arlo Technologies, Inc is not responsible for any failure to follow these battery usage guidelines.

Arlo Technologies, Inc.
2200 Faraday Ave. Suite 150 July 2018
Carlsbad, CA 92008 USA

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every
Angle Covered are trademarks of Arlo Technologies,
Inc. Other trademarks are for reference purposes only.



203-11594-03