



## WC3015S3S Parts list

No.	No. of parts	Parts Name	Qty
1	US2-14	Strainer	1
2	US3-110	Water tank	1
3	US1-32	Power cord	1
4	US1-54	Compressor (ESD55UB)	1
5	US3-14	The cover of Power box	1
6	US5-1	Power PCB	1
7	US3-13	Power box	1
8	US4-68-BR	Right Upper hinge	1
8.5	US4-68-BL	Left Upper hinge	1
9	US1-6	The fan of evaporator	1
10	US1-53	Heater	1
11	US3-50	The carbon filter	1
12	US3-75	Air-duct Board	1
	US4-93	fan net	1
13	US3-49	The cover of the sensor	1
14	US1-9	Sensor	1
15	US1-28-W	Light	1
16	US3-12	Light cover	1
17	US5-13-1	Control PCB	1
18	US3-104	Control PCB supporter	1
19	US4-148	control box	1
20	BZ1-311	Sticker	1
21	US4-151-BR	The Right lower supporter of the door	1
21.5	US4-151-BL	The Left Lower supporter of the door	
22	MT03-22	Door with handle/gasket	1
23	US3-101	Small shelf	1
24	US3-102	Big shelf	5
25	US2-32	Copper Evaporator	1
26	US4-92-B	Lock Hook	1
27	US4-153-BR	Lower hinger(Right)	1
27.5	US4-153-BL	Lower hinger(Left)	1
28	US4-147	The front vent	1
29	US2-28	Condensor	1
30	US3-45	Feet	4
31	US2-10	Circle pipe	1
32	US4-52	Bracket for fan	2
33	US1-52	The fan of condensor	1
34	US4-75	The bottom plate	1