

Installation Using an AV Cable
(Integrated Audio/Video)

PlayStation2 computer entertainment system (70000 series)
Step 1: CABLES



Connect the flat end of the AV Cable to the AV MULTI OUT connector on the back of the PlayStation 2 system.



Connect the plugs on the other end of the cable to the audio and video inputs on the back of your television or VCR. Make sure the connections are secure.

Note: For best results, connect directly to the TV when using the system to watch DVDs.



Connect the AC adaptor to the AC power cord. Connect the AC adaptor to the PlayStation 2 console.



Plug the AC power cord into a working electrical outlet.

Step 2: CONTROL



Press the on/standby/reset button on the front of the console. Make sure the indicator light turns green.



Press the open button on the front of the console and set a disc in the disc holder. Press down gently on the disc until all three tabs on the disc holder are above the surface of the disc. Press the "PUSH" label on the disc cover to close it.

Step 3: CONTROL



Turn on the power to your TV.



On your TV remote control, press the TV/VIDEO button. This button may also be labeled as:

- INPUT
- AUX
- LINE

If you need further installation assistance, contact Consumer Services at:

1-800-345-SONY
(1-800-345-7669)
MON - SAT 6:00 AM - 8:00 PM PST
SUN 7:00 AM - 6:30 PM PST