

DST Setting Module : 5146

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, press (C) button several times.

1.



In the Timekeeping Mode, hold down (A) button for about three seconds.

2.



City code will flash in the upper display.

3.



Press (C) button once.

4.



DST setting (ON or OFF) will appear in the lower display.

5.



Press (D) button to toggle ON and OFF.

6.



Press (A) button to exit the setting screen.