



WELCOME TO GOLDEN TEE® GO™!

Congratulations on your purchase of Golden Tee GO! All you need to get up and running is the Power Cable inside the box, your GO cabinet, and this slick little quick start guide.

REGISTER YOUR GAME


Register your game and stay in the know with news, tips, videos and more at:

<https://www.goldentee.com>

Visit the LIVEWIRE at goldentee.com and download the GT Caddy app for the full Golden Tee experience!

POWER UP

Connect the power cable to the Power Supply input on the back of the GO cabinet. Then plug the cable into a 3-pronged, grounded wall socket. Locate the power ON/OFF switch on the back of the cabinet and turn it ON. **YOU ARE NOW READY TO PLAY!**



CONNECT TO YOUR HDTV (Optional)

To bring the excitement of Golden Tee GO to a larger screen in your home, connect a HDMI cable (not supplied) to the HDMI output on the back of the unit and connect the other end of the HDMI cable to the proper HDMI input on your HDTV. On the HDTV menu, select the appropriate HDMI Input.

To use the speakers from your TV, press the System Menu button on the GT GO cabinet and select SOUNDS from the menu. Select Digital Audio and follow the onscreen instructions. Your game will restart to make this change from the internal analog speaker to your external speakers through HDMI.

GAME FEATURES

- Play on 32 high-def 18-hole courses
- 1 to 4 players can play
 - Select 18-hole play, 9-hole Closest to the Pin and multi-player Skins games
- Use the Options button to select premium balls and clubs

- Connects to optional external TV via HDMI

GAME CONTROLS

- 1 - LEFT
Pivot Golfer to Left
Decrease Volume with 3
- 2 - RIGHT
Pivot Golfer to Right
Increase Volume with 3
- 3 - FLY-BY
Tap for Course Overview
Press & Hold with:
1 = Decrease Volume
2 = Increase Volume
- 4 - TRACKBALL
Menu - Scroll Options
In-game - Scroll Clubs
Pull Back, Push Forward to Shoot Ball



- 5 - HELP
Menu Help
In-game - Birdseye View
- 6 - OPTIONS
See Options Menu below
- 7 - SPIN
Add Backspin when Ball Lands
- 8 - START/REPLAY
Menu - Select Option
Start or Replay Game

OPTIONS MENU

Customize Golfer – Select your golfer and choose from a variety of outfits

Equipment Setup – Optimize the equipment your golfer uses in the game

Mulligan – After taking a shot you can choose to re-take the shot or mulligan

Lock Quickshot – Quickshot speeds up your shot for faster gameplay

Hide Shot Meter – Turn the trackball meter display off or on

Player Quit – Quit the current game

Return to Game – Return from Options Menu

SYSTEM MENU

Settings – Difficulty, Timer, Mulligans, Pre-Game Clothing, Reset Leaderboards & Records, Reset to Factory, Store Demo Mode

Sounds – In Game Volume, Attract Volume, Attract Sounds, Digital Audio

System – Video Tests, Sound Tests, Player Control Tests, Hardware Tests





Incredible Technologies, Inc.
200 Corporate Woods Parkway
Vernon Hills, IL 60061

Phone (847) 870-7027 (800) 262-0323
www.goldentego.com