

# **Quick Start Guide**

For complete operational guidelines, please refer to your user manual.

# **GETTING STARTED**

- Flip the power switch to ON to check current battery level.
- The LED battery indicator will turn on.
- The unit will enter into "Setup Wizard" mode, please choose "Home" for regular use.

**Wall Outlet** 

# **BLUETOOTH CONNECTION**

#### **Manual Bluetooth Pairing**

- Place speaker and Bluetooth device within 3 feet of each other.
- Make sure the Bluetooth function is enabled on your device.
- Press and hold the Bluetooth button for 2 seconds to enter pairing mode.
   BLUE LED will flash.
- Search for Bluetooth devices on you device. Select "MONSTER VISION".

# **AUX INPUT**

- Plug in the 3.5 mm Stereo Audio wire into the AUX-IN input,
- Press AUX IN key and the unit will enter into AUX mode. BT LED indicator will turn off.
- You can connect any audio device that has a 3.5 mm audio output jack, and can payback any audio from the connected device.

# **SOURCE SWITCHING KEY**

- Main unit has 4 Sources (Display/Bluetooth/Aux in/Radio)
   Press "Source" key on remote control to change between
   source DISPLAY/FM/AUX/BT sequence: DISPLAY/FM/AUX/BT
- The main unit supports 4 sources under audio mode:
  - 1. Display source (default source);
  - 2. FM source:
  - 3. AUX IN source;
  - 4. Bluetooth source.
- If Main unit is on in Display mode, it will have 4 sub-sources in Display mode. Press the video key on the unit OR press "TV"/"HDMI"/ "USB" button on Remote Control to change source between "TV"/ "HDMI1"/"HDMI2"/ "USB"; the related source message will show on TV screen;

\*If they unit is not in use, power should be switched off
\*Unit should be recharged every 2 months if not in constant use.