Body-solid



Assembly & Instructions

GS-348Q OWNER`S MANUAL

GS348Q PARTS

(shown in actual size)

G [1PCS]



I [1PCS]



J [1PCS]



K [1PCS]



L [2PCS]



M[1PCS]



N [1PCS]



O [1PCS]



R [2PCS]
8312-062

S [4PCS]
8312-091



P [2PCS]
8280-018



Q [1PCS]
8343-056

T [1PCS]
8343-056



U [1PCS]
8370-030



GS348Q PARTS

(shown in actual size)

A [1PCS]



B [1PCS]



C [2PCS]



D [1PCS]



E [1PCS]



F [6PCS]



H [1PCS]



GS348Q HARDWARE

(shown in actual size)

D1.50X75 End Cad(9211-084)----------[2PCS]
D2.ø49.5X Round End Cap(9211-074)----------[8PCS]
D3.ø1"Shaft Collar(9211-064)----------[2PCS]
D4.ø2 1/2"Xø26 Rubber Dount(9310-012)----------[2PCS]
D5.ø90X10t Rubber Dount(9310-016)----------[4PCS]
D6.38X325 Rubber Bar Catch(9310-042)----------[2PCS]
D7.45X70 Tape(9440-068)----------[12PCS]
D8.ø26 Round End Cap(9211-069)----------[2PCS]

D1



D2



D3



D4



D5



D6



D7



D8





GS348Q HARDWARE

(shown in actual size)

B1.M12 Nylon Lock Nut----------[22PCS]



B2.M10 Nylon Lock Nut----------[2PCS]

C1.M12(I.D) WASHER ⌀34----------[60PCS]



C2.M10(I.D) WASHER ⌀27----------[4PCS]





GS348Q HARDWARE

(shown in actual size)

A1. M12X25L Inner Hex Screw----------[2PCS]



A2. M12X70L Hex Head Bolt----------[6PCS]



A3. M12X80L Hex Head Bolt----------[16PCS]



A4. M12X85L Hex Head Bolt----------[4PCS]



A5.M12X90LHex Head Bolt----------[4PCS]



A6. M10X70L Hex Head Bolt----------[2PCS]



A7. M12X75L Hex Head Bolt----------[2PCS]





STEP 1



GS348Q
Above show STEP 1
assembled and completed



STEP 2



GS348Q
Above show STEP 2
assembled and completed



STEP

3



GS348Q
Above show STEP 3
assembled and completed



STEP 4



GS348Q
Above show STEP 4
assembled and completed



STEP 5



GS348Q
Above show STEP 5
assembled and completed



EXPLODED VIEW DIAGRAM GS348Q