

SHARP®

Simply Better Living

works with alexa



SMC1169HS

SMC1169HS / SMC1169KS 1.1 CU.FT. SMART MICROWAVE

Alexa Command List

SMC1169HS / SMC1169KS ALEXA COMMANDS

Pair with your Amazon Alexa App and enjoy hands-free cooking with Alexa.

MENU ITEM	COMMAND	QUANTITY RANGE
+ 30 Seconds	Alexa, add 30 seconds to the microwave.	100% Power
Add Time	Alexa, add X minutes to the microwave. Alexa, add Y seconds to the microwave.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Pause Time	Alexa, pause the microwave.	-
Resume Time	Alexa, resume the microwave.	-
Stop Time	Alexa, stop the microwave.	-
Time Cook	Alexa, microwave for X minutes and Y seconds. Alexa, cook for X minutes and Y seconds. Alexa, reheat for X minutes and Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Time Cook + Power Level	Alexa, microwave for X -minutes / Y -seconds at Z -power level. Alexa, cook for X -minutes / Y -seconds at Z -power level.	X = 01:00 - 60:00 Y = 00:01 - 00:59 Z = 0 -10 Power Level
Reheat	Alexa, reheat X oz of dinner plate. Alexa, reheat X oz of leftovers.	X = 9 / 12 / 18 oz
Time Defrost	Alexa, defrost for X minutes. Alexa, defrost for Y seconds. Alexa, defrost for X minutes Y seconds	X = 01:00 - 60:00 Y = 00:01 - 00:59
Beverage	Alexa, microwave beverage. Alexa, cook beverage. Alexa, microwave X cups of beverage. Alexa, cook X cups of beverage.	X = 1 / 2 / 3 cups
Meat (Auto Defrost)	Alexa, defrost meat. Alexa, defrost X pounds of meat.	X = 16 / 24 / 32 / 40 oz
Fish (Auto Defrost)	Alexa, defrost fish. Alexa, defrost X pounds of fish.	X = 8 / 16 / 24 / 32 oz
Poultry (Auto Defrost)	Alexa, defrost poultry. Alexa, defrost X pounds of poultry.	X = 24 / 32 / 40 oz
Fresh Vegetables	Alexa, microwave/cook X oz of fresh vegetables. Alexa, microwave/cook X oz of fresh veggies.	X = 4 / 8 / 16 oz

SMC1169HS / SMC1169KS ALEXA COMMANDS


MENU ITEM	COMMAND	QUANTITY RANGE
Frozen Pizza	Alexa, microwave X oz of frozen pizza. Alexa, cook X oz of frozen pizza.	X = 4 / 8 / 14 oz
Frozen Vegetables	Alexa, microwave/cook X oz of frozen vegetables. Alexa, microwave/cook X oz of frozen veggies.	X = 4 / 8 / 16 oz
Popcorn	Alexa, microwave/cook popcorn. Alexa, microwave/cook X oz of popcorn. Alexa, microwave/cook mini popcorn. Alexa, microwave/cook classic popcorn.	Mini / Classic X = 1.16 / 3.3 oz
Potato	Alexa, microwave X potato(es). Alexa, cook X potato(es).	X = 1 / 2 / 3



Simply Better Living



A THRIVING ONLINE COMMUNITY



Simply Better Living is an online community that encourages a mindful lifestyle with Sharp home appliances through simple recipes and lifestyle tips. Our lifestyle blog sbl.sharppusa.com is dedicated to creative, ingenious solutions that make your life simpler, healthier, and better than ever before. Welcome home.

Start your free-forever, weekly subscription to [Simply Better Living Newsletter](#) today! Every week we share tips, recipes, life hacks and articles to help support and invigorate your healthy lifestyle.

The key to a simply better you is [Simply Better Living!](#) Come and see.

Amazon, Echo, Alexa, and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

© 2023 Sharp Electronics Corporation. All rights reserved.

Sharp and all related trademarks are trademarks or registered trademarks of Sharp Corporation and/or its affiliated companies. All other trademarks are property of their respective owners.

QUESTIONS?

1.800.BE.SHARP

SIMPLY BETTER LIVING

At Sharp Home Electronics Company of America, we are committed to Simply Better Living. Our innovative home appliance products are SIMPLE to use, BETTER than the competition, and encourage a HEALTHY LIFESTYLE.

SHARP ELECTRONICS CORPORATION
100 Paragon Drive, Montvale NJ, 07645
1.800.237.4277 • www.sharppusa.com



Be Original.