


ASSEMBLY INSTRUCTION



Saldana LAF PC

Components






A
x1

Hardware List

a		Plastic Leg	Ø60x43mm	4
b		Plastic Washer	Ø8	4


Assembly Instructions




ASSEMBLY INSTRUCTION

Saldana LAF PC


Assembly of the sectionals



The prong and the connector must be aligned well.



How to disconnect



Lift up the right sectional and pull it out .

