

Stressless® Max & Mike

Button Functions



Button 1:	Leg Rest
Button 2:	Seat/Back (2 Phase) #1: TV Viewing #2: Sleep
Button 3:	Headrest Articulation
Button 4:	Home/Reset