



# Quick Connect Guide

## for LCD HDTVs

1

### Verify Box Contents

Power cable, remote control, two batteries, user manual and warranty card

### Identify Connections

Please see chart to the right to determine video quality

### Base Removal

See instructions in the user manual

2

### Connect external source devices

Indicate devices used in the Notes column


### Connect RF Antenna

If using a cable or settop box, skip channel scan

### Power on TV

Connect power cable to wall outlet  
Press power button on keypad or remote

### Follow On-Screen Setup Menu



3

### Power on external source devices

### Press input button on remote

Use input list to select source device

### Setup and verify external source devices

### Enjoy your new Westinghouse TV!

\*For DVD combo models insert DVD and go!



We recommend using HD programming for the best viewing experience!



Auto source  
detection and  
switching



Optimal day or  
night viewing



Easy side cable  
access



Organized cable  
management

## Quick Connection Reference

SK/VK/TX Series	Source Devices							
Connector Type	TV Input	Over-the-air	Cable/Satellite	DVD	Game Console	VHS	PC	Notes
HDMI		N/A	Best	Best	Best	N/A	Best	
YPbPr + LR Audio		N/A	Better	Better	Better	N/A	N/A	
VIDEO + LR Audio		N/A	Good	Good	Good	Good	N/A	
VGA + Audio Mini Jack		N/A	N/A	N/A	N/A	N/A	Best	
ANT		Best	N/A	N/A	N/A	N/A	N/A	



**Customer Service**  
866-287-5555



**Wall Mounts**  
Go to [www.wde.com](http://www.wde.com) to see which Westinghouse mounts are compatible with your LCD TV.



Go to [www.wde.com](http://www.wde.com) to check out the complete line of Westinghouse LCD products.