


(Actual Radio Appearance may differ from representation.)


Touareg Non-Navigation Radio (Advanced Mode) PGHW2 harness with PGHW2A adaptor

VOLKSWAGEN iPod



Browsing Example:


To select the song "Star-Spangled Banner" through the Artist category




(Actual Radio Appearance may differ from representation.)

Touareg Non-Navigation Radio (Advanced Mode) PGHW2 harness with PGHW2A adaptor


HD Radio
Pure Digital. Clear Radio.




HD RADIO EXAMPLE To select an HD radio station.



To store a radio station into preset memory.



To recall a station stored into preset memory.



Changing Modes:

Press the "CAT FLDR" button to toggle through the supported Media Gateway modes, AM, FM, AUX, IPOD, SAT and HD RADIO. When the desired source is displayed, wait 3 seconds, and the radio will automatically select the displayed option. NOTE: if you are in the factory Satellite Radio source, First press the in the tune knob twice, then use the "CAT FLDR" button to cycle through options as described above.