

# Samsung GALAXY Tab<sup>®</sup> 2

# Samsung GALAXY Note<sup>™</sup> 10.1



This 30 pin to USB connection pocket-size device turns your Galaxy Tab into a USB host, allowing you to connect compatible USB accessory devices such as keyboards, mice, thumb drives and more to your Tab. The adapter enhances the capabilities of your Tab, providing a solution for user-friendly removable data storage or the sharing of your favorite multimedia files with your Tab. Insert a USB memory stick or USB cable from compatible devices to the USB port on the adapter and then insert the adapter into your Tab.

## PRODUCT HIGHLIGHTS

- USB device for memory stick, mobile printing and camera connection
- Save and show USB images on your Tab
- Small size makes it ideal for travel

## USB Connection Kit

### EPL-1PLOBEGXAR

## FEATURES

- IF Connector: 30 pin
- Input: USB devices and cable
- USB Extension: print, camera and memory stick

## DIMENSIONS

- Product Dimensions: 0.3"D x 1.2"W x 1.7"H
- Package Dimensions: 0.7"D x 2.4"W x 3.9"H
- Product Weight: 0.02 lbs
- Package Weight: 0.1 lbs

## ORDER CODE

EPL-1PLOBEGXAR

## UPC CODE

635753492590

## COMPATIBILITY (All 2011 and 2012 Galaxy Tab Models)

- Galaxy Tab 2 7.0 (GT-P3113TSYXAR)
- Galaxy Tab 2 10.1 (GT-P5113TSYXAR)
- Galaxy Note 10.1 (GT-N8013EAVXAR)
- Galaxy Tab 7.0 Plus (GT-P6210MAYXAR, GT-P6210MAVXAR)
- Galaxy Tab 8.9 (GT-P7310MAYXAR, GT-P7310MAVXAR)
- Galaxy Tab 10.1 (GT-P7510MAYXAB, GT-P7510UWYXAB, GT-P7510MAVXAB, GT-P7510UWVXAB)

The Samsung logo is displayed in white capital letters inside a blue oval shape.