



HERE ARE SOME HELPFUL TIPS FOR GETTING TO KNOW YOUR MICRO

GETTING STARTED

Make sure your fully charge your Micro. The first time you power up a new Micro it will simply turn on – the power switch is on the rear. Micro will emit a turn-on tone.

TO PAIR TO YOUR DEVICE

After you power up your Micro, press and hold the multi-function button “O” on the top of the Micro. The LED will flash red to blue and you will hear a sonar sound. You can then release the button. Enable the Bluetooth function on your device just like you would to pair a wireless headset. Look for “Monster Micro” on your device and select it to connect. You will hear voice prompts to guide you until this process is finished. It may continue for a few seconds after you connect.

Micro will say “your device is connected” and emit a chime tone.

After the initial connection, each time you turn on your Micro it will seek the last device it was connected to. If the device is turned on and in range it will connect automatically. Micro will narrate the process and emit a chime tone when completed.

Please wait for the pairing process or the re-connect process to complete before operating the Micro.

HOW TO USE THE VOICE COMMANDS

Micro comes with voice commands off. To activate voice commands, hold + and – buttons together for about 5 seconds. Micro will say “the voice command is on”.

To turn off voice commands repeat the process – Micro will say “the voice command is off”.

You will still get voice acknowledgments of certain functions at all times – these are not part of the voice commands.

Say the trigger word “HELLO MONSTER MICRO” before EVERY voice command.

This is designed so that you can't accidentally give micro a command to do something. Micro will NOT respond without the trigger command first.

When Micro says “say a command” pause for a heartbeat before you issue the command. Speak clearly, and normally, you do not have to yell.

For a list of commands, when Micro says “say a command” respond with “what can I say” and Micro will recite the list of commands for you.

Always wait until Micro finishes talking before issuing a command.

When using micro “give it time” to complete its cycles. When you trigger the voice command, pause for a heartbeat before you give it a voice command.

Remember that micro cannot listen and talk at the same time – if you talk to micro while it is talking it will not understand.

Make sure you turn the music off before attempting voice commands.

Micro will NOT respond to the trigger if you do not stop the music on your device first. When you stop the music, wait a few seconds for the Bluetooth to disengage. Micro will emit a chime tone to let you know. Occasionally in voice command mode you can trigger the Micro’s voice command without realizing it. Anytime someone says “Monster Micro” in conversation it can trigger the voice command and Micro will say “say a command” That is what it supposed to do – it is not an error.

Non American English Accents and voice commands.

We have done a great deal of testing to make Micro as reliable as possible but we can’t guarantee that it will recognize all accents. Speak in a normal conversational voice for best results.

PLAYING MUSIC

Start your music and press and hold the volume up button on your Micro. Micro will make a “tick” sound so you know when you are all the way up. Then you can control the volume from your device.

BUTTON FUNCTIONS**Micros buttons perform many functions.**

When playing music the buttons on Micro control the music as well as the volume.

For volume you must PRESS AND HOLD the + or – buttons

A quick press on the O (multifunction) button is play/pause

A quick press on the + will advance the track

A quick press on the – will restart the track or go to the previous track

The meaning of the LED colors.

Flashing Blue - (when plugged in to charger or computer) – charging

Solid Blue – (when not plugged in and charging) - On

Red – battery low

Flashing red – battery EXTREMELY low

Red/Blue rapid flash – pairing mode

Blue when playing music – SBC Bluetooth Codec active

Green when playing music – AAC Codec active

Purple when playing music – apt-X Codec active

For more information and videos about Monster Micro – visit our website.

<http://www.monstercable.com/headphones/clarityHD/>