NETGEAR°





Getting Started

Update Your Push2TV

NETGEAR recommends that you update Push2TV as new updates may support even more wireless display devices.

- Use your laptop or mobile device to visit www.netgear.com/ptv and download new firmware.
- Press and hold the Push2TV side button for 7 seconds.
- On your laptop or mobile device, find and connect to the Push2TV WiFi network name (SSID).
- 4. Open a browser and type http://192.168.3.1 in the URL bar.
- Upload the firmware and install it.

For information about updating Intel Wireless Display software on your laptop, visit http://www.intel.com/go/wirelessdisplayupdate.

Getting to Know Push2TV



Wirelessly mirror your Wi-Fi CERTIFIED Miracast™ or Intel WiDi enabled laptop, smartphone, or tablet. Now you can enjoy photos, videos, music, or any websites on your big-screen TV.

Package Contents



Push2TV adapter




USB power cable



Power adapter (varies by country)

Set Up Your Adapter



Connect Push2TV to your TV and plug in the power adapter.

Connect with Intel WiDi

To connect with Miracast devices, go to page 11.

Step 1

Turn on your TV and select the correct HDMI input source.

The **Ready for connection** screen displays on your TV.



On your laptop, launch the Intel WiDi software.



Use the Intel WiDi software to find and connect to Push2TV.



The first time that you connect your laptop to Push2TV, enter the security code on the TV in the Intel WiDi software on your laptop.



Congratulations

You are now displaying your laptop screen wirelessly on your TV.





Connect with Miracast

To connect with Intel WiDi, go to page 6.

Step 1

Turn on your TV and select the correct HDMI input source.

The **Ready for connection screen** displays on your TV.



Find the wireless display app on your Wi-Fi CERTIFIED Miracast smartphone, laptop, or tablet.

The name and location of the app might differ by device.



Samsung Galaxy S III



Sony Xperia T



Google Nexus 4

Use the wireless display software to find and connect to Push2TV.



Follow the instructions on your TV to do one of the following:

Enter a security code.

OR

Press the Push2TV side button.



Congratulations

You are now displaying your smartphone screen wirelessly on your TV.





Tips for Enjoying Push2TV

- To display different content on the TV while you use your laptop, change the screen display setting on your laptop to extend mode.
- You can mute your laptop and still watch videos with sound.
- You can stop your laptop from going to sleep when you close the lid while you use wireless display.
 - From Windows, select **Start > Search**, type **closing lid** in the search field, and change the setting to **do nothing**.

FAQs

Q Why can't I play some DVD and Blu-ray discs?

Many discs have copy protection mechanisms that prevent playback on Intel Wireless Display software version v2.1.0.0 and earlier. Personal content that you burn to a disc does play.

Q What should I do if the TV stops showing my laptop screen?

Use Intel Wireless Display software to check the wireless connection and reconnect to Push2TV. Also, try moving your laptop closer to the adapter or to a location with a clear line of sight to the adapter.

Q How can I restore the Push2TV factory settings?

Use a paper clip to press and hold the **Reset** button for 10 seconds.



About Wi-Fi CERTIFIED Miracast and Intel WiDi

- For a list supported devices, visit www.netgear.com/landing/stream/tv/#push2tv#devices.
- To check for the latest Intel WiDi software on your laptop, visit www.intel.com/go/wirelessdisplayupdate.

For Intel WiDi system requirements, visit www.intel.com/support/wireless/wtech/iwd/sb/CS-031059.htm. Thank you for selecting NETGEAR products. After installing your device, locate the serial number on the label and use it to register your product at https://my.netgear.com.

You must register your product before you can use NETGEAR telephone support.

For product updates and web support, visit http://support.netgear.com. The user manual is available at http://downloadcenter.netgear.com.

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. © NETGEAR, Inc. All rights reserved.

For the current EU Declaration of Conformity, visit: http://support.netgear.com/app/answers/detail/a_id/11621/.

Intended for indoor use only in all EU member states, EFTA states, and Switzerland.

