

KitchenAid®

**6 QT. STAND MIXER
GLASS BOWL - BOWL LIFT**

MODELS:

KSM6521XOB0 (Onyx Black)


KSM6521XCA0 (Candy Apple)

KSM6521XFP0 (Frosted Pearl)

KSM6521XMS0 (Medallion Silver)

KSM6521XSR0 (Sugar Pearl Silver)

COLOR VARIATION PARTS




COLOR VARIATION PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing
	9705296	Onyx Black
	W10403016	Candy Apple
	W10454050	Frosted Pearl
	W10354887	Medallion Silver
2	W10520271	Sugar Pearl
		Trim Band
3	W10568273	Dark Platinum
		Lower Gearcase
	W10410012	Onyx Black
	W10403004	Candy Apple
	W10454059	Frosted Pearl
	W10354881	Medallion Silver
	W10520260	Sugar Pearl

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Planetary
	W10410018	Onyx Black
	W10403008	Candy Apple
	W10520287	Frosted Pearl
	W10354883	Medallion Silver
5	W10520266	Sugar Pearl
		Bowl Support and Pins
	9705356	Onyx Black
	W10402998	Candy Apple
	W10448659	Frosted Pearl
	W10354878	Medallion Silver
	W10520248	Sugar Pearl

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Column and Pins
	9705320	Onyx Black
	W10402992	Candy Apple
	W10520203	Frosted Pearl
	W10354872	Medallion Silver
7	W10520205	Sugar Pearl
		Base and Foot Assembly
	9705344	Onyx Black
	W10402986	Candy Apple
	W10448638	Frosted Pearl
	W10354860	Medallion Silver
	W10520258	Sugar Pearl


CASE, GEARING AND PLANETARY UNIT



CASE, GEARING AND PLANETARY UNIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing (Refer to Color Variation Parts Page)	8	3400617	Screw	18	W10234643	Gear, Pinion
			9	3400814	Screw	19	9707223	Pin, Retaining
2	W10395280	Cap, Attachment Hub (Satin Chrome)	10	W10517938	Motor, 120 Volt Assembly	20	8533910	Washer
	9703315	Cap, Attachment Hub (Chrome)	11	3400200	Screw	21	9708191	Shaft, Agitator
3		Trim Band (Refer to Color Variation Parts Page)	12	W10545635	Control Assembly, 120 Volt	22	9703680	Clip, Retaining
			13	W10234531	Pin, Groove	23		Thumb Screw
4	W10351843	Screw	14		Cord, Power		W10512907	Chrome
5	W10305968	Holder, Control	15	W10338492	Black Planetary Assembly	24	9704677	Pin, Groove
6		Lower Gearcase (Refer to Color Variation Parts Page)			(Refer to Color Variation Parts Page)			
7	W10234493	Gear, Ring and Plate Assembly	16	9703438	Ring, Retaining			
			17	9706090	Washer			

BASE AND PEDESTAL UNIT



Literature Parts

BASE AND PEDESTAL UNIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Base and Foot Assembly	16	W10553964	Beater, Flat
	W10410027	Use and Care Guide, U.S.			(Refer to Color Variation Parts Page)	17	W10552542	Hook, Dough
2	9703698	Cap, Handle				18	9706885	Arm, Bowl Lift
3	W10532186	Bowl, Glass (6 Quart)	9	9708649	Foot	19	W10552543	Whip, Wire
4	240185	Pin, Retaining Bowl	10	9703307	Ring, Retaining	20	9703426	Cam, Adjusting
5	W10504114	Clip, Bowl Retainer	11	W10598835	Rod, Bowl Lift	21	3400863	Screw
6	3400018	Screw	12	9237	Spring, Lift Rod	22	W10598836	Handle, Bowl Lift
7		Bowl Support and Pins	13	9703439	Washer	23	3400200	Screw
		(Refer to Color Variation Parts Page)	14	8533907	Nut	24	W10559999	Lid, Glass Bowl (6 Quart)
			15		Column and Pins			
					(Refer to Color Variation Parts Page)			