

Hanover Outdoor Furniture



If you have any problems with this product (missing or damaged parts, assembly issues, etc.),

PLEASE DO NOT RETURN TO THE RETAILER/STORE

from where you purchased the product.

Please call our Toll-Free Customer Service Hotline at: **1-800-416-3511**Between 9:00 AM and 5:00 PM Eastern Time, Monday through Friday

Or visit our website at: www.hanover-products.com

To expedite any future warranty claims, please retain the Instruction Sheet, Warranty Card and receipt for future use.


For additional on-line support on assembly, troubleshooting and care & maintenance of your outdoor furniture, please visit our website at: **www.hanover-products.com**.

6/1/2015 (a)

IMPORTANT!! PLEASE READ ENTIRE INSTRUCTION SHEET BEFORE ASSEMBLY!! TO EXPEDITE WARRANTY CLAIMS PLEASE KEEP INSTRUCTION SHEET, WARRANTY CARD AND COPY OF RECEIPT

- Step 1: Identify all parts packed in the carton against the parts list. Remove all protective materials. If you are missing any parts or are unsure as how to proceed with the assembly, please call our Product Specialists immediately at 1-800-416-3511. Do not attempt to assemble the chair if any parts are damaged or missing.
- Step 2: With the help of another person, place table top upside down on a non-abrasive surface to avoid scratching the top of the rim. Identify the upper leg and lower leg. Insert the upper leg into lower leg as shown in Fig. 1.
- Step 3: Attach table legs to table top using a bolt and washer as shown in Fig. 2. Guide bolt through hole in table leg, into pre-drilled hole in the table top. **Do not over tighten.** Some adjustments may be necessary to ensure proper alignment of the table legs. Repeat for other three sides. Your table is now ready for use.

IMPORTANT NOTE: Damage to welds or frames resulting from over tightened bolts or improper assembly is not covered under our warranty. Please read all instructions carefully before assembly. If you have any questions regarding your assembly, call our Product Specialists at 1-800-416-3511.






Fig. 1

Fig. 2

* NOTE: PARTS SHOWN ON PARTS LIST ARE NOT TO SCALE				
	PARTS LIST	DESCRIPTION	ORDER PART #	QTY
A		TABLE TOP		1
В		LOWER LEG		1
С		UPPER LEG		1
D		1/4" X 42 MM BOLT	HW0039	4
Е	0	Ø6.5 X 1.0 MM WASHER	HW0004	4
F		HEX BOLT DRIVER	HW0006	1
		FOOT CAP FACTORY ASSEMBLY	SZ5450	

* NOTE: PARTS SHOWN ON PARTS LIST ARE NOT TO SCALE

BPS03723