# K40 RL360i / RL200i QUICK REFERENCE GUIDE

## **Customizable Settings**

To access and change any of the factory default settings:

- Press and release MENU). The RL360i / RL200i will announce, "Menu," along with the status of the first customizable setting.
- **Press and release** MENU to scroll through the options until you get to the feature you want to change.
- **Press and release** or + to change an existing setting.

The system will automatically save settings and exit after 10 seconds.

| Menu Options<br>(in order presented) |                          | Factory Default Setting |
|--------------------------------------|--------------------------|-------------------------|
| 1                                    | Voice Type               | Female                  |
| 2                                    | Audible Voice            | On                      |
| 3                                    | Wake-Up                  | Wake-Up Long            |
| 4                                    | Auto Mute                | Off                     |
| 5                                    | POP Radar                | Off                     |
| 6                                    | mph / kph                | mph                     |
| 7                                    | Speed Monitor            | Off                     |
| 8                                    | Front Radar              | On                      |
| 9                                    | Front X-Band             | On                      |
| 10                                   | Front K-Band             | On                      |
| 11                                   | Front Ka-Band            | On                      |
| 12                                   | Rear Radar               | On*                     |
| 13                                   | Rear X-Band              | On*                     |
| 14                                   | Rear K-Band              | On*                     |
| 15                                   | Rear Ka-Band             | On*                     |
| 16                                   | Laser Defuser (optional) | On                      |
| 17                                   | Laser Setting            | Laser Constant Transmit |
| 18                                   | Factory Reset            |                         |

## **Frequently Used Features**

#### Mute Audio Before or During Alert (Owner's Manual pg. 8)

| <b>30-second Mute</b> or duration of alert | Press and release MUTE.            |
|--|------------------------------------|
| Extended Mute<br>(5 minutes)               | Press and hold MUTE for 3 seconds. |

#### Mark to Alert / Mark to Mute (Owner's Manual pgs. 9-10)

| Alert/Mute<br>Location             | Press and release MA or MM when you are at a location you wish to store in your database. |
|------------------------------------|---|
| Remove an Alert/<br>Muted Location | Press and release MA or MM while at that location.  |
| Remove All<br>Stored Locations     | Press and hold MA or MM for 5 seconds at any time.  |

### Activating / Adjusting Quiet Ride (Owner's Manual pg. 8)

- **Press and release** QR to activate the Quiet Ride menu. Voice will announce the current setting of Quiet Ride.
- Use or to adjust the speed settings on Quiet Ride. Any selected speed setting indicates Quiet Ride is on.
- When you have made your speed selections, stop scrolling and Quiet Ride will announce, "Quiet Ride Set."