

Key Features

Product Information

Product Category	Integra Dishwashers
Product Series	300 Series
Product Name	Integra 300 Series Dishwasher
Model Number	SHX43C0xUC
Color	Stainless Steel
Also available in	White, Black

Convenience

RACKMATIC™

RACKMATIC™ by Bosch makes loading your dishes and platters of all sizes a snap, anytime. Now you can raise and lower the upper rack without having to remove the dishes.



Stainless Steel TALLTUB™

Simply put, the Bosch **TALLTUB** provides you with an extremely efficient use of space. Top and bottom racks can be adjusted for improved clearance, and if you remove the top rack altogether, you're left with an incredible 22" of usable space. It doesn't get bigger than that.

Silverware Basket

Available with select packages, the flexible silverware basket can be separated in two and placed anywhere inside, like on the top rack when using the Top Rack Only Wash option. Our standard model keeps silverware free from tangles with a flip-up lid that separates utensils, ensuring the most perfect of clean.

Top Rack Only™

The Bosch Top Rack Only™ wash option is perfect for times when you don't have time for a full load. And because the tub is so tall, you can practically put anything up here, including dishes, stemware and silverware. This convenient feature saves you water and energy, too.

PERFECTDOOR™

Falling dishwasher doors are finally a thing of the past. All Bosch dishwashers feature **PERFECTDOOR**, which stays in a fixed position whenever it is opened more than 10°.

Optional Delay Start

With a nineteen or twenty-four hour timer, Bosch dishwashers work on your schedule. Program them to start once guests leave or after you've drifted off to sleep. Wait until you're out of the house, or even run it during the evening, potentially saving money on your energy bill.

AUTOCLOSE™

This ingenious design automatically closes the dishwasher door in a smooth, silent motion once it is less than 10° from vertical, without any user intervention.