

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.



# NINJA CRISPI®

PORTABLE GLASS COOKING SYSTEM

## Quick start guide

Recipes, charts, and  
how-tos to get cooking



# Welcome to your all-in-one portable glass cooking system

Now you've got the power of a full-sized air fryer in the palm of your hand. Read on for tips, tricks, and how-tos for your Ninja CRISPi® Air Fryer.



**Snap it**



**Crisp it**



**Serve it**




**Store it**

## Table of Contents

Get to know the Ninja® CRISPi®	4
Meet your CleanCrisp™ starter set	5
Get to know the control panel	8
4-in-1 functionality	9
Crisping dishes	10
Recrisping leftovers	11
Your easy guide to weekly meal planning	14
Create a personal CRISPi® meal	16
Kickstarter recipes	18
Recipes	26
Cooking charts	50

## Meal prep made easy

Get all the glassware you need to make your weekly meals a breeze.



**SCAN HERE**  
for tips and recipes,  
and to add to  
your glassware  
collection.


Get yours at [ninjakitchen.com/accessories](https://ninjakitchen.com/accessories)



**4-qt Glassware**



**2.5-qt Glassware**



**6-cup Glassware**

# Get to know the Ninja® CRISPi®

1500-watt air fryer in a lightweight PowerPod™

**CRISPi® PowerPod**  
Senses which CleanCrisp Glassware you're using and adjusts cooking temperature.

**NOTE:** Colors and functions may vary by model.

## Big Batch Container Adapter

Adapts the PowerPod to fit the 4-qt container. No adapter needed for the 2.5-qt glassware.

## SAFE ON



GRANITE



LAMINATE



QUARTZ



MARBLE



TILE



WOOD

## Counter-safe feet

Set the glassware down on any countertop surface with durable heat-safe feet.



## Easy-to-store design

PowerPod can be stacked on top of nested glassware.

## Safe on counters

The PowerPod and adapter's durable heat-safe feet allow both to be placed safely on granite, laminate, quartz, butcher block, and marble.

## Crisper plate

Allows air to evenly circulate under and around food for the perfect all-over crisp.

## CleanCrisp™ Glassware

Glassware designed for nontoxic cooking and storing.

# CleanCrisp™ GLASSWARE

**NO PFAS | NO PTFE | DISHWASHER-SAFE**

Glassware designed for nontoxic cooking and storing.

## CleanCrisp™ Glassware is safe on

Granite, Laminate, Butcher Block, Quartz, Marble



## 4-qt Glassware

Feed up to 6 people

### PERFECT FOR:

Large proteins like whole chickens or roasts and more



## 2.5-qt Glassware

Quick personal meals

### PERFECT FOR:

Everyday sides and snacks

# Get to know your glassware

## Snap-on lid (x2)

For easy storage of leftovers.



## Crisper plate (x2)

Allows air to evenly circulate under and around food for the perfect all-over crisp.




## 4-qt Glassware

Fits a 4-lb chicken or roast.



## Permanent easy-grip handles

Non-removable handles stay secure and make for easy transport from kitchen to table.



## SAFE ON



**Counter-safe feet**  
Set the glassware down on any countertop surface with durable heat-safe feet.

## 2.5-qt Glassware

Best for sides and personal meals.

## TAKE ON THE GO



## NESTING STORAGE



## SNACKS AND PARTY FAVORITES



## MEAL PREP



## REHEAT AT WORK



**CleanCrisp**  
GLASSWARE



**EXPLORE  
POWERPOD™  
ATTACHMENTS**  
Your master cooking  
system starts here.



## 6-cup Glassware

Best for personal portions  
and single-serve meals



## 2.5-qt Glassware

Best for sides to  
complete the perfect meal



## 4-qt Glassware

Feed up to 6 people

# Get to know the control panel

Simplified cooking with 4 functions.



# 4-in-1 functionality

Go from low heat to high heat with 4 cooking functions.

See the cooking charts at the end of this book for more information.

**Low Heat**

380°F-400°F

375°F-400°F

400°F-425°F

**High Heat**

425°F-450°F

**Recrisp**



Revive leftovers with an even, crispy texture.

**Bake**



Bake desserts and breads to a perfect golden brown.

*Best for prepared or scratch bread and cookie doughs.*

*NOTE: Thin liquid batters (such as cakes and cheesecakes) are not recommended. Thicker batters (such as muffins and brownies) **MUST** be baked using standard-sized silicone or foil muffin liners placed on the crisper plate. Also, reduce recommended cook time by 50%.*

**DO NOT POUR BATTERS DIRECTLY INTO CONTAINERS.**

**Air Fry**



Crisp your favorite foods to perfection with little to no oil.

**Max Crisp**



Get an extra-crispy crunch with rapid high heat.

*Best for prepackaged frozen foods.*

## Getting started

**1**

### Power

Press to turn the CRISPi PowerPod™ on/off, pause/start cooking, or hold for 2 seconds to turn off while cooking.

**2**

### Select mode

Press the mode button to select the desired cook function.

**3**

### Adjust time

The mode will start with a suggested time. Press - or + to adjust the cook time before or during cooking.

## How to pause cooking

To pause a cook, remove CRISPi PowerPod. To resume cooking, place PowerPod back on container and press START.

# Crisping dishes

Air fry fresh or frozen food to perfection.

## How to Crisp

**Bake**  
375°F-400°F

**Air Fry**  
400°F-425°F

**Max Crisp**  
425°F-450°F

### 1 Add crisper plate

### 2 Add food

Prep with seasoning or marinade if needed. *Tip: You can marinate directly in the glassware container.*

### 3 Attach PowerPod™ and select mode

If using the small container, place PowerPod on container, ensuring it is aligned properly. If using the large container, insert PowerPod in the adapter until the front and back click into place, then place assembled PowerPod and adapter on container. Select mode and adjust time as needed.

### 4 Toss occasionally

Lift the PowerPod to turn or toss ingredients using silicone-tipped tongs once or twice during cooking.

#### Safe sense

Cooking will automatically pause when you remove the PowerPod from the container. To resume cooking, place PowerPod on container and press START.


### 5 Serve

TempGuard containers can be placed directly on any countertop surface.




**Note:** PowerPod can be set down on any countertop surface with durable, heat-safe prongs.

#### Large (4 qt)



#### Small (6 cup)



#### Tips:

- Use the adapter for the large container and remove the adapter for the small container.
- To safely remove adapter from pod, allow to cool before handling. Push pod backward while holding down center tab on adapter to release.

# Recrisping leftovers

Revive leftovers into new dishes.

## How to Re crisp

**Re crisp**  
380°F-400°F

### 1 Add foods for warming (optional)

Add any foods you want to warm but not crisp (pasta, rice, etc.) to the bottom of the container.

### 2 Add crisper plate

### 3 Add foods for crisping

Add foods that you want to crisp (proteins, veggies, etc.).

### 4 Attach PowerPod and select mode


Place PowerPod on container. Select Re crisp. Cook for 10-15 minutes or until food is heated.

### 5 Remove crisper plate and serve

Use a fork to remove the crisper plate, then serve. TempGuard containers can be placed directly on any surface.

**Tip:** The small 6-cup TempWare container is the perfect size for leftovers.

**Note:** See the Re crisp Chart at the end of this book for more information.



# CRISPi® Kickstarter Recipes

## Ready to start crisping?

Learn how to make crispy snacks and full meals in minutes.

### FLIP TO FIND:

Your easy guide to weekly meal planning	14
Create a personal CRISPi® meal	16
Kickstarter recipes	18
Recipes	26
Cooking charts	50



4 QT  
BIG BATCH  
Kickstarter

### Cheesy Loaded Tots

Pages 22-23 | Beginner recipe



4 QT  
BIG BATCH  
Kickstarter

### Teriyaki-Glazed Wings

Pages 24-25 | Beginner recipe



6 CUP  
SMALL BATCH  
Kickstarter

### Buffalo Chicken Dip

Pages 18-19 | Beginner recipe



6 CUP  
SMALL BATCH  
Kickstarter

### Marinated Steak Tips with Baby Potatoes

Pages 20-21 | Beginner recipe

# Your easy guide to weekly meal planning

BREAKFAST

MONDAY

French Toast Sticks & Sausage  
(6-cup glassware)



See pages 26-27  
for recipe.

TUESDAY

Apple Turnovers  
(6-cup glassware)



See page 48  
for recipe.

WEDNESDAY

Frozen Egg Bites  
(6-cup glassware)



See pages 52-53  
for Air Fry Chart.

THURSDAY

Hashbrown Patties  
(6-cup glassware) with  
scrambled eggs



See pages 52-53 for Air Fry  
Chart. Serve with scrambled  
eggs for a full meal.

FRIDAY

Sweet Potato Hash  
(4-qt glassware)



See pages 48-49 for  
Air Fry Chart. Combine sweet  
potatoes, peppers, and spices  
to create a crispy hash.

LUNCH

Marinated Steak Tips  
with Baby Potatoes  
(6-cup glassware)



See pages 20-21  
for recipe.

Air-Fried Chicken Breast  
(6-cup glassware) served over  
fresh salad



See pages 50-51  
for Air Fry Chart.

Meatloaf Sandwich  
(with last night's meatloaf  
leftovers)  
(6-cup glassware)



See pages 58-59  
for recrip inspiration.

Teriyaki Shrimp with Bell  
Peppers & Broccoli  
(6-cup glassware)



See pages 16-17  
to create your CRISPI meal.

Leftover Meatballs & Pasta  
(6-cup glassware)



See pages 58-59  
for recrip inspiration.

DINNER

Teriyaki-Glazed Wings  
(4-qt glassware) served  
with prepared white rice  
or fresh salad



See pages 24-25  
for recipe.

Classic Meatloaf  
(4-qt glassware) served  
with sides of choice



See page 37  
for recipe.

Crispy Whole Chicken  
(4-qt glassware) served  
with roasted potatoes



See pages 38-39 for recipe,  
add baby potatoes or  
vegetable of choice.

Meatballs (4-qt glassware)  
with marinara sauce & pasta



See pages 52-53  
for Air Fry Chart. Serve  
with freshly cooked pasta.

Philly Cheesesteaks  
(4-qt glassware)



See pages 40-41  
for recipe.

Use the Big Batch and Small Batch glasswares to cook breakfast, lunch, and dinner for the week. Follow this guide for inspiration and add your favorite recipes and ingredients as desired.

## Key:

Use the colors below to meal prep in each container.

4-QT  
GLASSWARE



6-CUP  
GLASSWARE



**TIP:** Craving dessert too? CRISPI can do that! Refer to pages 48-49 for dessert recipes.



# 6-CUP GLASSWARE

Create a personal CRISPi meal.

## Step 1 Pick your protein

- POULTRY**
  - 2 OR 3 BONELESS, SKINLESS CHICKEN THIGHS (8 oz. total)
  - 1 BONELESS, SKINLESS CHICKEN BREAST (8 oz.)
  - 6 FROZEN CHICKEN NUGGETS (6 oz.)
- BEEF**
  - 1 SIRLOIN STEAK (6-8 oz.)
  - 6 FRESH OR FROZEN MEATBALLS (1 oz. each)
  - 1/2 POUND STEAK TIPS
  - 1 CUP GROUND BEEF (6 oz, broken into chunks)
- FISH/SEAFOOD**
  - 8-10 LARGE FRESH OR FROZEN SHRIMP (peeled, deveined)
  - 1 SALMON FILLET (6 oz.)
- PORK**
  - 1 BONELESS PORK CHOP (8 oz.)
  - 2 PORK OR CHICKEN SAUSAGES (3 oz. each)
- PLANT-BASED**
  - TOFU**  
About 1 cup (6 oz.), cut in 1-inch pieces or sticks
  - PLANT-BASED MEAT**  
About 1 cup (6 oz.), broken into chunks

**TIP:** For quicker cooking, cut protein in 1-inch pieces and cook on AIR FRY for 10-15 minutes.

**TIP:** For extra flavor, place protein on crisper plate in container and brush on all sides with 2 Tbsp marinade. Refrigerate for 30 minutes to overnight. Add vegetable to crisper plate when ready to cook.

## Step 2 Pick your vegetable

1/2 cup (4 oz.) crisper plate

- ASPARAGUS**  
(fresh or frozen), trimmed, cut in 2-inch pieces
- BELL PEPPERS**, seeded, cut in 1-inch pieces
- BROCCOLI**  
(fresh or frozen), cut in 1-inch florets
- BRUSSELS SPROUTS**, trimmed, cut in half
- FROZEN CARROTS**
- CAULIFLOWER**, cut in 1-inch pieces
- GREEN BEANS**  
(fresh or frozen), trimmed, cut in 2-inch pieces
- ZUCCHINI**, cut in 1-inch pieces
- EGGPLANT**, cut in 1-inch pieces
- FROZEN FRENCH FRIES**
- FROZEN SWEET POTATO FRIES**
- MUSHROOMS**  
cut in 1/4-inch slices

**TIP:** Toss vegetable in 1 Tbsp oil and season as desired.  
Mix and match vegetables as desired (for best results, do not combine fresh and frozen vegetables).

## Step 3 Top it

as desired

**Place protein and vegetable side by side on crisper plate. Cook on AIR FRY for 15-20 minutes.**

Flip contents halfway through cooking for even doneness.

**NOTE:** Ensure food reaches these food-safe temperatures:

- BEEF: 145°F-155°F**
- FISH/SEAFOOD: 145°F**
- PORK: 145°F**
- POULTRY: 165°F**
- VEGETABLES: 165°F**

- TERIYAKI SAUCE
- BUFFALO SAUCE
- RANCH
- PEANUT SAUCE
- MARINARA SAUCE
- BARBECUE SAUCE
- BALSAMIC GLAZE
- SESAME SEEDS
- CRUNCHY FRIED ONIONS
- CHOPPED NUTS
- PICKLED VEGETABLES
- CRUMBLLED CHEESE (PARMESAN, FETA, GOAT, ETC.)
- FRESH HERBS

# Buffalo Chicken Dip

**Prep:** 10 minutes | **Cook:** 32 minutes | **Makes:** 4 servings

## Ingredients

- 1 cup cooked chicken breast, chopped
- 1 block (8 ounces) cream cheese, softened
- ½ cup sour cream
- 1 cup Buffalo sauce
- 2 cups shredded cheddar cheese, divided

## Directions



Place chicken in the Small Batch Container.



Attach CRISPi PowerPod to container, press MODE until MAX CRISP illuminates, set time to 32 minutes, and press START to begin cooking.



When 30 minutes remain on the timer, remove Powerpod and add cream cheese, sour cream, Buffalo sauce, and 1 cup cheddar cheese and stir to combine. Replace PowerPod and press START to resume cooking.



Small Batch | 6 cup

**Max Crisp**

BEGINNER RECIPE



When 5 minutes remain on the timer, remove PowerPod, stir dip, and top with remaining cheddar cheese. Place Powerpod back on container and press start to resume cooking.



Cooking is complete when internal temperature of dip reaches at least 165°F on an instant-read thermometer. Serve dip hot with crackers, chips, or sliced vegetables.

**TIP:** Prefer something less spicy? Create a barbecue chicken dip by swapping out the Buffalo sauce for barbecue sauce!

# Marinated Steak Tips with Baby Potatoes

**Prep:** 10 minutes | **Marinate:** 30 minutes–16 hours | **Cook:** 14 minutes | **Makes:** 1 serving

## Ingredients

- 6–8 ounces sirloin steak tips, cut in 1-2-inch pieces
- 2 tablespoons marinade of choice
- ½ cup (4 ounces) baby potatoes, cut in quarters
- ½ teaspoon extra virgin olive oil
- Kosher salt, as desired
- Ground black pepper, as desired

## Directions



Place crisper plate in the small batch container. Place steak tips on plate and evenly coat with marinade.



Cover container with lid and place in refrigerator to marinate for 30 minutes or up to 16 hours.




When ready to cook, arrange potatoes next to steak on crisper plate. Drizzle potatoes with olive oil, salt, and pepper.



Small Batch | 6 cup

**Air Fry**

BEGINNER RECIPE



Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 14 minutes, and press START to begin cooking.



When 7 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently turn steak and potatoes to ensure even cooking. Replace PowerPod and press START to resume cooking.



When cooking is complete, serve immediately.

**TIP:** No time to marinate? Use pre-marinated steak tips for a faster meal!

# Cheesy Loaded Tots

**Prep:** 5 minutes | **Cook:** 20-25 minutes | **Makes:** 4 servings

## Ingredients

2 pounds frozen tater tots  
2 cups shredded cheddar cheese

## Toppings (optional)

Sliced scallions  
Sliced jalapeño peppers  
Bacon bits  
Sour cream

## Directions



Place crisper plate in the Big Batch Container, then place tater tots on top.



Attach adapter to CRISPi PowerPod and place on the container. Press MODE to select MAX CRISP function, set time to 20 minutes, and press START to begin cooking.



When 10 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss tots to ensure even cooking. Replace PowerPod and press START to resume cooking.



Big Batch | 4 qt

**Max Crisp**

BEGINNER RECIPE



Ensure tater tots are golden and crispy, adding additional time if needed. When 1 minute remains on the timer, remove PowerPod and sprinkle cheese evenly over tots. Replace PowerPod and press START to resume cooking.



When cooking is complete, top tots as desired with sliced scallions, sliced jalapeños, bacon bits, sour cream and serve.

# Teriyaki-Glazed Wings

**Prep:** 5 minutes | **Marinate:** 30 minutes-16 hours | **Cook:** 40 minutes | **Makes:** 4-6 servings

## Ingredients

2 pounds chicken wings  
(drumettes and flats)

Kosher salt, as desired

Ground black pepper, as desired

$\frac{3}{4}$  cup teriyaki sauce, plus extra for serving

2 tablespoons scallions, thinly sliced (optional)

## Directions



Place crisper plate in the Big Batch Container then place wings on top. Add salt, pepper, and teriyaki sauce to wings and toss to coat.



Cover container with lid and place in refrigerator to marinate for 30 minutes up to 16 hours.



When ready to cook, attach adapter to CRISPi PowerPod and place on the container. Press MODE to select AIR FRY function, set time to 40 minutes, and press START to begin cooking.

**TIP:** Prefer a different glaze? Swap in barbecue sauce for the teriyaki.



Big Batch | 4 qt

**Air Fry**

BEGINNER RECIPE



When 30 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss wings. Replace PowerPod and press START to resume cooking. Toss again 2 more times, once when 15 minutes remain on the timer and again when 5 minutes remain on the timer.



When cooking is complete, add additional sauce if desired and toss to coat. Garnish as desired and serve warm.



## French Toast Sticks & Sausage

**Prep:** 2 minutes | **Cook:** 8 minutes | **Makes:** 1 serving

### Ingredients

4 frozen French toast sticks (approx. 4 ounces)

4 frozen breakfast sausage links

Maple syrup, for serving

### Directions

- 1 Place crisper plate in the Small Batch Container, then place French toast sticks and sausage links on top.
- 2 Attach CRISPi PowerPod to container, press MODE until MAX CRISP illuminates, set time to 8 minutes, and press START to begin cooking.
- 3 When 4 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently turn French toast and sausage links to ensure even cooking. Replace PowerPod and press START to resume cooking.
- 4 When cooking is complete, serve immediately with maple syrup or as desired.



Small Batch | 6 cup

**Max Crisp**

BEGINNER RECIPE



# Spicy Black Bean Nachos

Prep: 5 minutes | Cook: 8 minutes | Makes: 4 servings

## Ingredients

- 2 cups tortilla chips, divided
- 1 cup shredded cheddar cheese, divided
- ¼ cup + 2 tablespoons canned black beans, drained, rinsed, divided
- ¼ cup pickled jalapeño peppers, chopped, divided

## Toppings (optional)

- Sour cream
- Salsa
- Cilantro

## Directions

- 1 In the Big Batch Container, layer ingredients in the following order, ½ cup of chips, ¼ cup of cheese, approx. 2 tablespoons beans, and 1 tablespoon of jalapeños. Repeat 3 additional times for a total of 4 layers. Make sure to leave 3 inches of room between top layer of nachos and top lip of container.
- 2 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 8 minutes, and press START to begin cooking.
- 3 Cook until cheese is melted, adding additional time if needed.
- 4 When cooking is complete, top nachos with additional toppings like sour cream, salsa, and cilantro, as desired and serve hot.



# Stuffed Mushrooms

Prep: 15 minutes | Cook: 12 minutes | Makes: 4 servings

## Ingredients

- ¼ cup panko bread crumbs
- ¼ cup grated Parmesan cheese
- ½ cup ricotta cheese
- 1 tablespoon extra virgin olive oil
- ¼ teaspoon crushed pepper (optional)
- ¼ teaspoon garlic powder
- Kosher salt, as desired
- Ground black pepper, as desired
- 1 ½ tablespoons chopped parsley
- 1 pound cremini mushrooms, whole, stems removed

## Directions

- 1 Add all ingredients, except mushrooms, to a medium bowl and mix until smooth and combined. Then, evenly distribute the filling amongst the mushrooms caps.
- 2 Place crisper plate in the Big Batch Container, then carefully place mushrooms, filling side up, on top, layering as necessary.
- 3 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 12 minutes, and press START to begin cooking.
- 4 When 4 minutes remain on the timer, or when top mushrooms are golden brown, remove PowerPod and use silicone-tipped tongs to carefully remove top mushrooms from container and set aside. Replace PowerPod and press START to allow remaining mushrooms to cook.
- 5 When cooking is complete, serve stuffed mushrooms while hot.



**TIP:** Swap for any canned bean you have on hand!

# Lemon-Pepper Chicken Tenders

Prep: 2 minutes | Cook: 15 minutes | Makes: 4 servings

## Ingredients

1 pound frozen breaded chicken breast tenders  
1 ½ teaspoons lemon-pepper seasoning

## For serving

Ketchup  
Blue cheese  
Barbecue sauce  
Honey mustard sauce  
Other sauces of choice

## Directions

- 1 Place crisper plate in the Big Batch Container, then place chicken tenders on top.
- 2 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until MAX CRISP illuminates, set time to 15 minutes, and press START to begin cooking.
- 3 When 7 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss tenders to ensure even cooking. Replace PowerPod and press START to resume cooking.
- 4 When cooking is complete, add lemon-pepper seasoning and toss to coat. Serve tenders immediately with dipping sauce as desired.



Big Batch | 4 qt

Max Crisp

BEGINNER RECIPE



# Bacon Brussels Sprouts

Prep: 10 minutes | Cook: 17 minutes | Makes: 4 servings

## Ingredients

1 ½ pounds Brussels sprouts, trimmed, cut in half  
1 tablespoon extra virgin olive oil  
1 teaspoon kosher salt  
Ground black pepper, as desired  
4 strips uncooked bacon, cut in ¼-inch pieces  
2 tablespoons grated Parmesan cheese

## Directions

- 1 Place crisper plate in the Big Batch Container, then place Brussels sprouts on top.
- 2 Add oil, salt, pepper, and bacon, then use silicone-tipped tongs to gently toss to combine.
- 3 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 17 minutes, and press START to begin cooking.
- 4 When 9 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss sprouts to ensure even cooking. Replace PowerPod and press START to resume cooking.
- 5 When 4 minutes remain on the timer, remove PowerPod and sprinkle sprouts with Parmesan. Gently toss sprouts with silicone-tipped tongs to combine. Replace PowerPod and press START to resume cooking.
- 6 When cooking is complete, serve immediately.



Big Batch | 4 qt

Air Fry

BEGINNER RECIPE



**TIP:** Swap out lemon-pepper seasoning for your favorite spice blend.

# Garlicky Green Beans

**Prep:** 10 minutes | **Cook:** 20 minutes | **Makes:** 4-6 servings

## Ingredients

2 pounds green beans, ends trimmed  
3 tablespoons extra virgin olive oil  
4 large cloves garlic, peeled, minced  
Kosher salt, as desired  
Ground black pepper, as desired

## Directions

- 1 Place crisper plate in the Big Batch Container. Add green beans, oil, garlic, salt, and pepper, and toss with silicone-tipped tongs to coat.
- 2 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 20 minutes, and press START to begin cooking.
- 3 When 10 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss green beans to ensure even cooking. Replace PowerPod and press START to resume cooking.
- 4 When cooking is complete, serve immediately.



# Coconut Shrimp

**Prep:** 2 minutes | **Cook:** 15 minutes | **Makes:** 4 servings

## Ingredients

1 pound frozen breaded coconut shrimp  
Sweet chili sauce, for serving

## Directions

- 1 Place crisper plate in the Big Batch Container, then place shrimp on top.
- 2 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until MAX CRISP illuminates, set time to 15 minutes, and press START to begin cooking.
- 3 When 8 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss shrimp to ensure even cooking. Replace PowerPod and press START to resume cooking.
- 4 When 3 minutes remain on the timer, gently toss shrimp once more. Resume cooking.
- 5 When cooking is complete, serve immediately with sweet chili sauce or as desired.



**TIP:** Serve with chili oil for a little kick.

**TIP:** Make it a meal by serving with leftover or quick-cooking/instant rice.

# Prosciutto-Wrapped Asparagus

**Prep:** 5 minutes | **Cook:** 10–15 minutes | **Makes:** 2 servings

## Ingredients

½ pound thin asparagus spears, trimmed  
2 tablespoons extra virgin olive oil  
Kosher salt, as desired  
Ground black pepper, as desired  
8–10 slices prosciutto  
Balsamic glaze (optional)

## Directions

- 1 Coat asparagus with oil, salt, and pepper. Wrap 1 slice prosciutto around 5–7 asparagus stalks, creating a tightly wrapped bundle. Continue wrapping until all asparagus is bundled.
- 2 Place crisper plate in Small Batch Container, then place asparagus bundles on top. It is ok if the bundles overlap.
- 3 Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 10 minutes, and press START to begin cooking.
- 4 When 5 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently turn bundles. Replace PowerPod and press START to resume cooking.
- 5 Cook until browned and crispy, adding additional time if needed.
- 6 When cooking is complete, drizzle with balsamic glaze, if desired, and serve immediately.



Small Batch | 6 cup

**Air Fry**

BEGINNER RECIPE



# Garlic Knots

**Prep:** 5 minutes | **Cook:** 15 minutes | **Makes:** 4 servings

## Ingredients

1 pound prepared pizza dough, room temperature  
1 stick unsalted butter, cut into 1-inch pieces  
3 tablespoons minced garlic  
Kosher salt, as desired  
Ground black pepper, as desired  
¼ cup grated parmesan cheese  
1 tablespoon fresh basil, chopped

## Directions

- 1 Divide pizza dough into 8 equal pieces and roll each piece into a 6-inch rope then tie into a knot and allow to rest for 5 minutes.
- 2 Place butter, garlic, salt and pepper in the bottom of the Big Batch Container, add the crisper plate on top and then place knots on top of the crisper plate ensuring they are evenly spaced.
- 3 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until BAKE illuminates, set time to 15 minutes, and press START to begin cooking.
- 4 When cooking is complete, with an instant read thermometer, ensure internal temperature of knots are at least 200°F. Add additional cooking time if needed.
- 5 When desired doneness is achieved, remove crisper plate allowing knots to fall into butter mixture.
- 6 Toss knots to coat in butter mixture, sprinkle with parmesan cheese and fresh chopped basil, and serve while warm.



Big Batch | 4 qt

**Bake**

INTERMEDIATE RECIPE



# Herbed Chicken & Potatoes

Prep: 15 minutes | Cook: 40 minutes | Makes: 6 servings

## Ingredients

2 pounds baby potatoes  
1 small yellow onion, peeled, sliced ½-inch thick  
¼ cup extra virgin olive oil, divided  
1 teaspoon dried parsley  
1 teaspoon garlic powder  
1 tablespoon herbs de Provence  
6 boneless, skinless chicken breasts (5–6 ounces each)  
Kosher salt, as desired  
Ground black pepper, as desired  
Fresh chopped parsley, for garnish, as desired

## Directions

- 1 Place potatoes, onions, 2 tablespoons oil, dried parsley, garlic powder, salt, and pepper in the Big Batch Container and toss to combine.
- 2 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 40 minutes, and press START to begin cooking.
- 3 Place chicken breasts on plate or cutting board. Rub with remaining 2 tablespoons oil and season with herbs de Provence, salt, and pepper to taste.
- 4 When 25 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently toss potatoes. Then, place chicken over potatoes. Replace PowerPod and press START to resume cooking.
- 5 Cooking is complete when the internal temperature of chicken reaches at least 165°F on an instant-read thermometer. Add additional cooking time if needed.
- 6 Serve hot with fresh chopped parsley, as desired.



# Classic Meatloaf

Prep: 15 minutes | Cook: 40 minutes | Makes: 4–6 servings

## Ingredients

¼ cup whole milk  
2 large eggs  
2 tablespoons Worcestershire sauce  
½ cup seasoned bread crumbs  
1 cup crispy fried onions  
1 teaspoon Italian seasoning  
1 teaspoon garlic powder  
Kosher salt, as desired  
Ground black pepper, as desired  
2 pounds 90/10 lean ground beef

## Glaze

1 cup ketchup  
¼ cup apple cider vinegar  
3 tablespoons light brown sugar

## Directions

- 1 In a large bowl, combine milk, egg, Worcestershire sauce, bread crumbs, fried onions, and seasonings. Mix until completely combined with a paste-like consistency. Add ground beef and mix to combine. Shape mixture into a 2-inch thick loaf.
- 2 Place crisper plate in the large Big Batch Container, then place meatloaf on top.
- 3 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 40 minutes, and press START to begin cooking.
- 4 Prepare glaze by combining all glaze ingredients in a small bowl. Mix until brown sugar has completely dissolved.
- 5 When 5 minutes remain on the timer, remove PowerPod and brush half the glaze over the meatloaf. Replace PowerPod and press START resume cooking.
- 6 Cooking is complete when internal temperature of the meatloaf reaches at least 155°F on an instant-read thermometer. Add additional time as needed.
- 7 When cooking is complete, allow meatloaf to rest for 5 minutes before slicing and serving with remaining glaze.



# Crispy Whole Chicken

Prep: 5 minutes | Cook: 60 minutes | Makes: 4 servings

## Ingredients

3-4-pound whole roaster chicken, patted dry, giblets removed

2 tablespoons extra virgin olive oil

Kosher salt, as desired

Ground black pepper, as desired

Lemon wedges, for garnish

## Directions

- 1 Rub entire chicken with olive oil and season generously with salt and pepper.
- 2 Place crisper plate in the Big Batch Container, then place the chicken on top.
- 3 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 60 minutes, and press START to begin cooking.
- 4 Cooking is complete when internal temperature of chicken reaches at least 165°F on an instant-read thermometer. Add additional cooking time if needed.
- 5 Transfer chicken to a cutting board and let rest for 5-10 minutes before slicing. Serve hot with lemon wedges.



Big Batch | 4 qt

Air Fry

BEGINNER RECIPE



# Philly Cheesesteaks

**Prep:** 10 minutes | **Cook:** 30 minutes | **Makes:** 4 servings

## Ingredients

- 2 small bell peppers, thinly sliced
- 1 white onion, trimmed, peeled, thinly sliced
- 2 tablespoons extra virgin olive oil
- Kosher salt, as desired
- Ground black pepper, as desired
- 2 pounds sirloin steak, thinly sliced
- 5 slices American or provolone cheese
- 4 sub rolls, toasted

## Directions

- 1 Place bell peppers, onions, oil, salt, and pepper in the Big Batch Container, then toss gently to combine.
- 2 Place the adapter on the container, then install the CRISPi PowerPod in the adapter. Press MODE until AIR FRY illuminates, set time to 30 minutes, and press START to begin cooking.
- 3 Season steak with salt and pepper as desired.
- 4 When 23 minutes remain on the timer, remove PowerPod and place steak over peppers and onions. Replace PowerPod and press START to resume cooking.
- 5 Every 3–4 minutes, remove PowerPod and toss steak, peppers, and onions to ensure even cooking.
- 6 When 1 minute remains on the timer, remove PowerPod and place cheese slices in a single layer over steak mixture, then replace PowerPod and press START to resume cooking.
- 7 When cooking is complete, serve cheesesteaks on toasted sub rolls.



Big Batch | 4 qt

**Air Fry**

BEGINNER RECIPE



# Mini Pizzas

**Prep:** 5 minutes | **Cook:** 3-5 minutes | **Makes:** 1 serving

## Ingredients

- 1 English muffin, cut in half
- ¼ cup marinara sauce
- ¼ cup shredded mozzarella cheese

## Toppings (optional)

- Mini pepperoni
- Crumbled bacon
- Sliced olives
- Sliced banana peppers

## Directions

- 1 Top each English muffin half evenly with marinara, cheese, and toppings as desired.
- 2 Place crisper plate in the Small Batch Container, then place mini pizzas on top.
- 3 Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 3 minutes, and press START to begin cooking.
- 4 Cook until English muffin is toasted and cheese has melted, adding additional time if needed.
- 5 When cooking is complete, allow pizzas to cool for 1-2 minutes. Serve warm.



Small Batch | 6 cup

**Air Fry**

BEGINNER RECIPE



# Grilled Cheese

**Prep:** 5 minutes | **Cook:** 8 minutes | **Makes:** 1 serving

## Ingredients

- 2 slices white bread
- 3 slices American cheese
- 1 tablespoon mayonnaise, divided

## Fillings (optional)

- 2 slices deli ham
- 2 slices deli turkey
- ½ Roma tomato, thinly sliced
- 1 tablespoon pickled jalapeño peppers, diced

## Directions

- 1 Place cheese on both slices of bread, topping cheese with fillings as desired. Close the sandwich and spread mayonnaise evenly on both sides of sandwich.
- 2 Place crisper plate in the Small Batch Container, then place sandwich on plate.
- 3 Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 8 minutes, and press START to begin cooking.
- 4 When 5 minutes remain on the timer, remove PowerPod and use a nonstick spatula to gently flip sandwich. Replace PowerPod and press START to resume cooking.
- 5 When cooking is complete, cut grilled cheese in half and serve immediately.



Small Batch | 6 cup

**Air Fry**

BEGINNER RECIPE



**TIP:** If desired, swap out the English muffin for mini naan bread.

**TIP:** To ensure cheese adheres to bread while cooking, firmly press down on top slice of bread.

# Beef & Vegetable Skewers

**Prep:** 15 minutes | **Cook:** 7 minutes | **Makes:** 1 serving  
**Accessories:** 4 wooden skewers (3 ¾ inches long), soaked in water

## Ingredients

- 1 tablespoon extra virgin olive oil
- 1 teaspoon shawarma spice blend
- Ground black pepper, as desired
- ¼ teaspoon kosher salt
- ¼ pound sirloin steak, cut in 1-inch chunks
- ½ small red bell pepper, seeded, cut in 1-inch pieces
- ½ small red onion, peeled, cut in 1-inch pieces

## For serving (optional)

- Tzatziki sauce
- Pita bread



Small Batch | 6 cup

Air Fry

BEGINNER RECIPE



## Directions

- 1 In a small bowl, add oil, shawarma spice blend, pepper, salt, and mix to combine. Add beef, peppers, and onions to oil mixture, and toss to coat evenly.
- 2 Assemble skewers in following order (dividing ingredients evenly): beef, peppers, onions.
- 3 Place crisper plate in the Small Batch Container, then place skewers on top in a single layer.
- 4 Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 7 minutes, and press START to begin cooking.
- 5 When 3 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently flip skewers. Replace PowerPod and press START to resume cooking.
- 6 Cooking is complete when internal temperature of beef reaches at least 145°F on an instant-read thermometer. Add additional cooking time if needed.
- 7 When cooking is complete, serve immediately with tzatziki sauce and pita bread if desired.

# Crispy Taquitos

**Prep:** 15 minutes | **Cook:** 10 minutes | **Makes:** 2 servings

## Ingredients

- 1 cup cooked taco meat (beef, chicken, pork, or turkey)
- 2 tablespoons sour cream, plus extra for serving
- ½ cup shredded cheddar cheese
- ¼ teaspoon garlic powder
- 2 tablespoons salsa, plus extra for serving
- 8 corn tortillas (6-inch diameter), warmed
- Nonstick cooking spray

## Directions

- 1 In a small bowl, combine meat, sour cream, cheese, garlic powder, and salsa. Stir to combine.
- 2 Place 2 tablespoons meat mixture in each tortilla. Gently roll tortillas, ensuring filling does not spill out.
- 3 Place crisper plate in the Small Batch Container. Place 4 taquitos on plate, then lightly spray them with cooking spray.
- 4 Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 10 minutes, and press START to begin cooking.
- 5 When 4 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently flip taquitos. Replace PowerPod and press START to resume cooking.
- 6 When cooking is complete, transfer taquitos to a serving plate and cover with aluminum foil.
- 7 Repeat steps 3–6 for remaining taquitos. When cooking is complete, serve taquitos warm with additional salsa and sour cream if desired.



Small Batch | 6 cup

Air Fry

BEGINNER RECIPE



**TIP:** Soak wooden skewers in water for at least 15 minutes.



# Chicken Parmesan

**Prep:** 5 minutes | **Cook:** 15 minutes | **Makes:** 1 serving

## Ingredients

1 raw, pre-breaded, ready-to-cook chicken cutlet (6-8 ounces)

2-3 tablespoons marinara sauce

2-3 slices fresh mozzarella cheese

Fresh basil or parsley, for garnish (optional)

## Directions

- 1 Place chicken cutlet in the Small Batch Container.
- 2 Attach CRISPi PowerPod to container, press MODE until AIR FRY illuminates, set time to 15 minutes, and press START to begin cooking.
- 3 When 8 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently flip cutlet. Replace PowerPod to and press START resume cooking.
- 4 When 3 minutes remain on the timer, remove PowerPod and spread marinara sauce over chicken, then lay the slices of mozzarella cheese on top of the sauce. Replace PowerPod and press START to resume cooking.
- 5 When cooking is complete, garnish with fresh basil or parsley if desired. Serve immediately.



Small Batch | 6 cup

**Air Fry**

BEGINNER RECIPE



**TIP:** Serve with fresh or leftover pasta.

# Apple Turnovers

**Prep:** 5 minutes | **Cook:** 17 minutes | **Makes:** 1-2 servings

## Ingredients

¼ sheet (2 ounces) frozen puff pastry dough, thawed, rolled into 6 ½-inch square and cut into 2 triangles

¼ cup pre-made apple pie filling, divided

1 large egg, beaten

1 teaspoon course sugar, divided

## Glaze (optional)

2 tablespoons powdered sugar

1 teaspoon water

## Directions

- 1 Lay out the 2 triangles of puff pastry dough on a clean work surface. Place 2 tablespoons apple pie filling in the center of each square.
- 2 Brush edges of squares with egg, then fold into triangles and use a fork to press down and seal the edges.
- 3 Brush tops of each pastry with egg, then sprinkle each with ½ teaspoon sugar.
- 4 Place crisper plate in the Small Batch Container, then place pastries on top.
- 5 Attach CRISPi PowerPod to container, press MODE until BAKE illuminates, set time to 17 minutes, and press START to begin cooking.
- 6 When 5 minutes remain on the timer, remove PowerPod and use silicone-tipped tongs to gently flip pastries. Replace PowerPod and press START to resume cooking.
- 7 Prepare glaze by combining powdered sugar and water in a small bowl. Mix until combined and smooth, adding extra water ½ teaspoon at a time as needed.
- 8 When cooking is complete, drizzle with glaze and serve.



Small Batch | 6 cup

Bake

INTERMEDIATE RECIPE



# Blueberry Crisp

**Prep:** 5 minutes | **Cook:** 25 minutes | **Makes:** 2 servings

## Ingredients

1 ½ cups fresh blueberries, rinsed

2 teaspoons granulated sugar

2 teaspoons all-purpose flour

## Topping

3 tablespoons unsalted butter, melted

3 tablespoons packed light brown sugar

¼ cup all-purpose flour

¼ cup old-fashioned oats

⅛ teaspoon ground cinnamon

Pinch kosher salt

## For serving (optional)

Vanilla ice cream

Whipped cream

**TIP:** Swap blueberries out for your favorite fresh berries.



Small Batch | 6 cup

Bake

INTERMEDIATE RECIPE



## Directions

- 1 Place blueberries, sugar, and flour in the Small Batch Container. Gently stir to combine, evenly coating berries in sugar and flour.
- 2 In a small bowl, combine all topping ingredients and stir until well incorporated.
- 3 Sprinkle topping over berry mixture in even layer.
- 4 Attach CRISPi PowerPod to container, press MODE until BAKE illuminates, set time to 25 minutes, and press START to begin cooking.
- 5 When cooking is complete, allow to cool for 5 minutes, then serve with ice cream and/or whipped cream if desired.

# Big Batch Air Fry Chart

**NOTE:** If cooking smaller amounts of food, use the recommended function, but reduce the time. For best results, check food periodically and shake or toss it often until it reaches the desired doneness.

**NOTE:** Install crisper plate before cooking.


**NOTE:** When cooking multiple foods back to back, reduce cook time by 3–5 minutes to prevent overcooking.

**NOTE:** Be sure to first install the PowerPod in the adapter, then place the assembled pod and adapter on the large container.


INGREDIENT	AMOUNT	PREPARATION	OIL	FUNCTION	COOK TIME	INTERACTION
<b>VEGETABLES</b>						
Asparagus	2 bunches	Stems trimmed	Toss with 2 Tsp oil	AIR FRY	15–20 mins	None
Bell peppers	8 peppers	Seeded, cut in quarters	None	AIR FRY	25–35 mins	Flip halfway through cooking
Broccoli	2 heads (1 1/2 lbs)	Cut in 1-inch florets	Toss with 1 Tbsp oil	AIR FRY	15–20 mins	Toss halfway through cooking
Brussels sprouts	1 1/2 lbs	Cut in half, stems removed	Toss with 1 Tbsp oil	AIR FRY	15–20 mins	Toss halfway through cooking
Butternut squash	3 lbs	Peeled, cut in 1–2-inch pieces	Toss with 1 Tbsp oil	AIR FRY	25–30 mins	Toss halfway through cooking
Carrots	2 lbs	Peeled, cut in 1/2-inch pieces	Toss with 1 Tbsp oil	AIR FRY	25–30 mins	None
Cauliflower	1 large head (1 1/2 lbs)	Cut in 1-inch florets	Toss with 2 Tbsp oil	AIR FRY	20–25 mins	Toss halfway through cooking
Green beans	1 1/2 lbs	Trimmed	Toss with 1 Tbsp oil	AIR FRY	20–25 mins	Toss halfway through cooking
Kale (for chips)	3 cups, packed	Torn in pieces, stems removed	None	AIR FRY	10–15 mins	Toss halfway through cooking
Mushrooms	2 1/2 lbs	Rinsed, cut in quarters	Toss with 1 Tbsp oil	AIR FRY	20–25 mins	None
Sweet potatoes	2 1/2 lbs	Cut in 1/2-inch pieces	Toss with 1 Tbsp oil	AIR FRY	30–35 mins	Toss halfway through cooking
Zucchini	2 lbs	Cut in 1/2-inch rounds	Toss with 1 Tbsp oil	AIR FRY	20–25 mins	Toss halfway through cooking
<b>POULTRY</b>						
Chicken breasts, boneless	5–6 breasts (6–8 oz. each)	None	None	AIR FRY	20–25 mins	None
Chicken drumsticks	6 each (1 1/2 lbs)	None	None	AIR FRY	15–20 mins	None
Chicken wings	2 lbs	Drumettes & flats	1 Tbsp	AIR FRY	30–35 mins	Toss twice during cooking
<b>SEAFOOD</b>						
Crab cakes	4 cakes (6–8 oz. each)	None	Brush with oil	AIR FRY	15–20 mins	None
Salmon fillets	4 fillets (4 oz. each)	None	Brush with oil	AIR FRY	10–15 mins	None
Shrimp	2 lbs	Whole, peeled, tails on	Toss with 1 Tbsp oil	AIR FRY	15–20 mins	None

**For best results, shake or toss often.**

For best results, flip food halfway through cooking. We recommend frequently checking your food and flipping with silicone-tipped tongs to ensure desired results. Use these cook times as a guide, adjusting to your preference.



**OR**



# Big Batch Air Fry Chart, continued

**NOTE:** If cooking smaller amounts of food, use the recommended function, but reduce the time. For best results, check food periodically and shake or toss it often until it reaches the desired doneness.

**NOTE:** Install crisper plate before cooking.


**NOTE:** When cooking multiple foods back to back, reduce cook time by 3–5 minutes to prevent overcooking.

**NOTE:** Be sure to first install the PowerPod in the adapter, then place the assembled pod and adapter on the large container.


INGREDIENT	AMOUNT	PREPARATION	OIL	FUNCTION	COOK TIME	INTERACTION
<b>BEEF</b>						
Burgers	4 patties, 80% lean (1/4 lb each), 1-inch thick	None	None	AIR FRY	10–15 mins	Flip halfway through cooking
Hot dogs	18 each	None	None	AIR FRY	10–15 mins	Flip halfway through cooking
Meatballs, fresh	12 meatballs (2 oz. each)	None	None	AIR FRY	15–20 mins	None
Steaks	5 steaks (6 oz. each)	None	None	AIR FRY	10–15 mins	None
Strip steaks	2 steaks (10–12 oz. each)	None	None	AIR FRY	15–20 mins	None
<b>PORK</b>						
Bacon	8 strips, cut in half	None	None	AIR FRY	10–15 mins	None
Pork chops	5 boneless chops (8 oz. each)	None	Brush with oil	AIR FRY	15–20 mins	None
Pork tenderloin	2 tenderloins (1–1 1/2 lbs), cut in half	Whole	Brush with oil	AIR FRY	30–35 mins	Flip halfway through cooking
Sausages	8 sausages	Whole	None	AIR FRY	15–20 mins	None
<b>FROZEN FOODS</b>						
Burgers	4 patties, 80% lean (1/4 lb each)	None	None	MAX CRISP	15–20 mins	None
Chicken nuggets	1 1/2 boxes (1 1/2 lbs)	None	None	MAX CRISP	15–20 mins	Toss halfway through cooking
Egg bites	9 bites (2 oz. each)	None	None	MAX CRISP	10–15 mins	None
Fish fillets	1 box (6 fillets)	None	None	MAX CRISP	10–15 mins	None
Fish sticks	18 fish sticks (11 oz.)	None	None	MAX CRISP	10–15 mins	Flip halfway through cooking
French fries	2 lbs	None	None	MAX CRISP	30–35 mins	Toss halfway through cooking
Hashbrown patties	5 patties (10 oz.)	None	None	MAX CRISP	10–15 mins	Flip halfway through cooking
Mozzarella sticks	2 boxes (11 oz. each)	None	None	MAX CRISP	10–15 mins	Flip halfway through cooking
Pizza rolls	2 bags (20 oz. each)	None	None	MAX CRISP	10–15 mins	Toss halfway through cooking
Popcorn shrimp	2 boxes (14–16 oz. each)	None	None	MAX CRISP	15–20 mins	Toss halfway through cooking
Pot stickers	2 bags (12 oz. each)	None	None	MAX CRISP	20–25 mins	Flip halfway through cooking
Sweet potato fries	1 bag (20 oz.)	None	None	MAX CRISP	10–15 mins	Flip halfway through cooking
Tater tots	1 bag (32 oz.)	None	None	MAX CRISP	20–25 mins	Toss halfway through cooking

**For best results, shake or toss often.**

For best results, flip food halfway through cooking. We recommend frequently checking your food and flipping with silicone-tipped tongs to ensure desired results. Use these cook times as a guide, adjusting to your preference.



**OR**



# Small Batch Air Fry Chart

**NOTE:** If cooking smaller amounts of food, use the recommended function, but reduce the time. For best results, check food periodically and shake or toss it often until it reaches the desired doneness.

**NOTE:** Install crisper plate before cooking.


**NOTE:** When cooking multiple foods back to back, reduce cook time by 3-5 minutes to prevent overcooking.

**NOTE:** Recrisp up to 2 1/2 pounds of food in the Big Batch (4-qt container) for 15-20 minutes, or until internal temperature reaches 165°F.


INGREDIENT	AMOUNT	PREPARATION	OIL	FUNCTION	COOK TIME	INTERACTION
<b>VEGETABLES</b>						
Asparagus	4 oz.	Trimmed, cut in half	Toss with 1 Tbsp oil	AIR FRY	8-10 mins	Toss halfway through cooking
Bell pepper	8 oz.	Seeded, cut in strips	None	AIR FRY	10-15 mins	Toss halfway through cooking
Broccoli	1 small head	Cut in 1-inch florets	Toss with 1 Tbsp oil	AIR FRY	8-10 mins	Toss halfway through cooking
Brussels sprouts	8 oz.	Trimmed, cut in half	None	AIR FRY	10-12 mins	Toss halfway through cooking
Butternut squash	8 oz.	Peeled, cut in 1/2-inch pieces	None	AIR FRY	10-15 mins	None
Carrots	8 oz.	Cut in 1/2-inch pieces	None	AIR FRY	10-15 mins	None
Cauliflower	6 oz.	Cut in 1-inch florets	None	AIR FRY	10-15 mins	Toss halfway through cooking
Green beans	6 oz.	Trimmed	None	AIR FRY	10-15 mins	Toss halfway through cooking
Kale (for chips)	2 oz.	Torn in pieces, stems removed	None	AIR FRY	4-5 mins	None
Mushrooms	6 oz.	Rinsed, cut in quarters	None	AIR FRY	10-15 mins	None
Sweet potato	1/2 lb (1-2 medium)	Cut in 1/2-inch pieces	Toss with 1 Tbsp oil	AIR FRY	20-25 mins	Toss halfway through cooking
Zucchini	1/2 lb (1-2 medium)	Cut in 1/2-inch rounds	Toss with 1 Tbsp oil	AIR FRY	15-20 mins	Toss halfway through cooking
<b>POULTRY</b>						
Chicken breasts, boneless	1 breast (6-8 oz.)	None	Brush with oil	AIR FRY	15-20 mins	None
	1 breast (6-8 oz.)	Cut in 1 1/2-2-inch pieces	Toss with 1 Tbsp oil	AIR FRY	10 mins	None
Chicken drumsticks	2 drumsticks (8 oz.)	None	None	AIR FRY	12-15 mins	None
Chicken wings	3/4 lb (12 oz.)	Drumettes & flats	None	AIR FRY	20-25 mins	Toss halfway through cooking
<b>SEAFOOD</b>						
Crab cakes	2 cakes (6-8 oz. each)	None	None	AIR FRY	10-15 mins	None
Salmon fillets	2 fillets (4 oz. each)	None	Brush with oil	AIR FRY	10-15 mins	None
Shrimp	8 oz.	Whole, peeled, tails removed	None	AIR FRY	8-10 mins	Flip halfway through cooking
<b>BEEF</b>						
Burgers	2 patties, 80% lean (1/4 lb each)	None	None	AIR FRY	10-15 mins	None
Hot dogs	4 hot dogs	Whole	None	AIR FRY	10-15 mins	Flip halfway through cooking
Meatballs, fresh	5 meatballs (2 oz. each)	None	None	AIR FRY	8-12 mins	None
Steak	1 steak (10-12 oz.)	None	None	AIR FRY	10-15 mins	None
Strip steak	1 steak (6-8 oz.)	None	None	AIR FRY	15 mins	None
<b>PORK</b>						
Pork chops	2 chops (6-8 oz. each)	None	None	AIR FRY	15-20 mins	None
Pork tenderloin	1 loin (25-30 oz.)	Cut in thirds	None	AIR FRY	20-25 mins	None
Sausages	4 sausages	None	None	AIR FRY	10-15 mins	None

**For best results, shake or toss often.**

For best results, flip food halfway through cooking. We recommend frequently checking your food and flipping with silicone-tipped tongs to ensure desired results. Use these cook times as a guide, adjusting to your preference.



**OR**



# Small Batch Air Fry Chart, continued

**NOTE:** If cooking smaller amounts of food, use the recommended function, but reduce the time. For best results, check food periodically and shake or toss it often until it reaches the desired doneness.

**NOTE:** Install crisper plate before cooking.


**NOTE:** When cooking multiple foods back to back, reduce cook time by 3-5 minutes to prevent overcooking.

**NOTE:** Recrisp up to 2 1/2 pounds of food in the Big Batch (4-qt container) for 15-20 minutes, or until internal temperature reaches 165°F.


INGREDIENT	AMOUNT	PREPARATION	OIL	FUNCTION	COOK TIME	INTERACTION
<b>FROZEN FOODS</b>						
Burger	1 patty (1/3 lb)	None	None	MAX CRISP	15-20 mins	None
Chicken nuggets	1/2 box (6 oz., 10 count)	None	None	MAX CRISP	10 mins	None
Egg bites	4 bites (2 oz. each)	None	None	MAX CRISP	10-15 mins	None
Fish fillets	3 fillets (2 oz. each)	None	None	MAX CRISP	10-15 mins	None
Fish sticks	8 fish sticks (6 oz.)	None	None	MAX CRISP	8-10 mins	None
French fries	1/2 lb	None	None	MAX CRISP	10-15 mins	Toss halfway through cooking
Hashbrown patties	2 patties (4 oz.)	None	None	MAX CRISP	10-15 mins	Flip halfway through cooking
Mozzarella sticks	1 box (8 oz.)	None	None	MAX CRISP	6-8 mins	None
Pizza rolls	1/2 bag (10 oz., 20 count)	None	None	MAX CRISP	8-10 mins	None
Popcorn Shrimp	1/2 lb	None	None	MAX CRISP	8-10 mins	None
Pot stickers	1/2 bag (6 oz., 8 count)	None	None	MAX CRISP	8-10 mins	None
Sweet potato fries	1/2 lb	None	None	MAX CRISP	10-15 mins	Toss halfway through cooking
Tater tots	1 1/4 cups	None	None	MAX CRISP	10-15 mins	Toss halfway through cooking

**For best results, shake or toss often.**

For best results, flip food halfway through cooking. We recommend frequently checking your food and flipping with silicone-tipped tongs to ensure desired results. Use these cook times as a guide, adjusting to your preference.



**OR**



# Small Batch Recrisp Chart

**NOTE:** If cooking smaller amounts of food, use the recommended function, but reduce the time. For best results, check food periodically and shake or toss it often until it reaches the desired doneness.

**NOTE:** Install crisper plate before cooking.


**NOTE:** When cooking multiple foods back to back, reduce cook time by 3-5 minutes to prevent overcooking.

**NOTE:** Recrisp up to 2 1/2 pounds of food in the Big Batch (4-qt container) for 15-20 minutes, or until internal temperature reaches 165°F.


INGREDIENT (COLD/REFRIGERATED & PRE-COOKED)	AMOUNT	PREPARATION	CRISPER PLATE ORIENTATION	FUNCTION	COOK TIME	INTERACTION
<b>VEGETABLES</b>						
Baked potato	1 large baked potato (8-10 oz.)	Cut in half	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	Flip halfway through cooking
Broccoli	6 oz. (approx. 2 cups)	Cut in 1-inch florets	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Toss halfway through cooking
Brussels sprouts	8 oz. (approx. 2 cups)	Trim ends, cut in half	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Toss halfway through cooking
Roasted baby potatoes	approx. 2 cups	Cut in half	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	None
Zucchini	10 oz. (approx. 2 cups)	Cut in 1/4-inch slices	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Toss halfway through cooking
<b>PROTEINS</b>						
Chicken breast/thigh	8 oz.	Cut in 1-inch slices	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	None
Chicken nuggets	8-10 pieces (6 oz.)	None	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	None
Chopped pork or brisket	8 oz. (approx. 2 cups)	Chopped or pulled	Place food in container, then place crisper plate on top	Recrisp	5-10 mins	None
Hamburger patty	1 patty (4 oz.)	None	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	None
Meatballs	10-12 oz. (approx. 2 cups)	None	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	Stir halfway through cooking
Pork tenderloin	8 oz.	Cut in 1/2-inch slices	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	None
Salmon	2 fillets (12 oz.)	None	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	None
Steak	8 oz.	Cut in 1-inch slices	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	None
Shrimp	10-12 large shrimp (6 oz.)	None	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Flip halfway through cooking
Turkey breast	8 oz.	Cut in 1/2-inch slices	Place crisper plate in container, then place food on top	Recrisp	8-10 mins	None

**For best results, shake or toss often.**

For best results, flip food halfway through cooking. We recommend frequently checking your food and flipping with silicone-tipped tongs to ensure desired results. Use these cook times as a guide, adjusting to your preference.



**OR**



# Small Batch Recrisp Chart, continued

**NOTE:** If cooking smaller amounts of food, use the recommended function, but reduce the time. For best results, check food periodically and shake or toss it often until it reaches the desired doneness.

**NOTE:** Install crisper plate before cooking.


**NOTE:** When cooking multiple foods back to back, reduce cook time by 3-5 minutes to prevent overcooking.

**NOTE:** Recrisp up to 2 1/2 pounds of food in the Big Batch (4-qt container) for 15-20 minutes, or until internal temperature reaches 165°F.


INGREDIENT (COLD/REFRIGERATED & PRE-COOKED)	AMOUNT	PREPARATION	CRISPER PLATE ORIENTATION	FUNCTION	COOK TIME	INTERACTION
<b>LEFOVER FAVORITES</b>						
Breakfast sandwich	1 sandwich (6-8 oz.)	Cut in half	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Flip halfway through cooking
Burrito		None	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Flip halfway through cooking
Chinese takeout (Lo Mein)		None	Place food in container, then place crisper plate on top	Recrisp	5-10 mins	Mix halfway through cooking
Dumplings	8 oz. (approx. 2 cups)	Add 1 tablespoon water over dumplings	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	None
French fries	4 oz. (approx. 2 cups)	None	Place crisper plate in container, then place food on top	Recrisp	3-5 mins	None
Grilled cheese	1 sandwich (approx. 4 oz.)	Cut in half	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Flip halfway through cooking
Pancakes	1 pancake (approx. 2 oz.)	None	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Flip halfway through cooking
Pasta	6 oz. (approx. 2 cups)	Add 1 tablespoon water	Place food in container, then place crisper plate on top	Recrisp	3-5 mins	Stir halfway through cooking
Pizza slice	1 slice (2 1/2 oz.)	None	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	None
Quesadilla	1 small quesadilla (approx. 4 oz.)	Cut in half	Place crisper plate in container, then place food on top	Recrisp	5-10 mins	Flip halfway through cooking
Rice	2 cups (8 oz.)	Add 1 tablespoon water	Place food in container, then place crisper plate on top	Recrisp	5-10 mins	Stir halfway through cooking

**For best results, shake or toss often.**

For best results, flip food halfway through cooking. We recommend frequently checking your food and flipping with silicone-tipped tongs to ensure desired results. Use these cook times as a guide, adjusting to your preference.



**OR**



**CleanCrisp™**  
GLASSWARE



**FEWER DISHES.  
MORE OPTIONS.**

Scan the QR code to  
get extra containers  
in a range of sizes.

**NINJA**  
**CRISPI®**  
PORTABLE GLASS COOKING SYSTEM

**FN101 Series\_IG\_QSG\_REV\_Mv16**

NINJA is a registered trademark of SharkNinja Operating LLC.  
NINJA CRISPI, POWERPOD, and TEMPWARE are trademarks of SharkNinja Operating LLC.

© 2025 SharkNinja Operating LLC.