


# BOLLARD SPEAKER POOR SOIL INSTALLATION

## INSTRUCTIONS

When dense clay soils exist it is best to make sure water can properly drain below the Bollard Speakers to prevent them from moving or shifting after installation.

- 1 Excavate a hole based on the size of your speaker (see below).
- 2 Fill the lower 1/3 of the hole with clean stone (1/2"-3/4") and compact with a hand tamper.
- 3 Carefully lower the speaker into the hole, making sure you allow 1" below the base of the sub grill (10.0 3-Way & 10.0 Subwoofer) or 1" below the drainage outlet (10.0 2-Way & 10.0 Subwoofer).
- 4 Backfill around the diameter of the speaker with existing soil or clean sand, compacting in 6" lifts.



Please visit [coastalsource.com](http://coastalsource.com) for more information or call us at 1-800-719-1996. You will always be pleased you purchased a Coastal Source product.

p. 800.719.1996  
[info@coastalsource.com](mailto:info@coastalsource.com)  
[coastalsource.com](http://coastalsource.com)

**CORPORATE OFFICE**  
 1270 GLEN AVENUE  
 MOORESTOWN, NJ 08057