


## Panel Dimensions

### Pinch Hazard

**CAUTION:** Installation of door panels with less than a 3/8" (9.5 mm) gap between the door panel and the adjacent cabinet increases the risk of potential pinching.

### Door Panels

**NOTE:** Following panel dimensions will provide 1/4" (6.4 mm) reveals.



F. Freezer Door Panel  
G. Refrigerator Door Panel

	42" Models	48" Models
A	17 <sup>5</sup> / <sub>8</sub> " (448 mm)	20 <sup>1</sup> / <sub>8</sub> " (511 mm)
B	23 <sup>5</sup> / <sub>8</sub> " (600 mm)	27 <sup>1</sup> / <sub>8</sub> " (689 mm)
H1	75 <sup>1</sup> / <sub>4</sub> " (1911 mm)	

## Fully Integrated Grille



J. Top Grille Panel

	42" Models	48" Models
C	41 <sup>1</sup> / <sub>2</sub> " (1054 mm)	47 <sup>1</sup> / <sub>2</sub> " (1207 mm)
H2	6 <sup>1</sup> / <sub>4</sub> " (159 mm)	

## Standard Grille



J. Top Grille Panel  
K. 1" (25.4 mm)

	42" Models	48" Models
D	41 <sup>1</sup> / <sub>4</sub> " (1048 mm)	47 <sup>1</sup> / <sub>4</sub> " (1200 mm)
E	41 <sup>1</sup> / <sub>2</sub> " (1054 mm)	47 <sup>1</sup> / <sub>2</sub> " (1207 mm)
H3	5 <sup>3</sup> / <sub>8</sub> " (137 mm)	

## Standard Grille Installation Requirements

### IMPORTANT:

- Use the standard grille bracket (provided with refrigerator) to attach the standard grille.
- Both Standard and Fully Integrated Grille installations can be achieved in the Flush and Overlay configurations.
- The grille panel layout, shown in the "INSTALLATION SIDE VIEW" illustration, allows for an air flow gap critical to the refrigerator.

### Standard Grille Bracket

